


OPERATOR'S MANUAL

■ ALPHA-1500

■ ALPHA-3100



For technical assistance or the Water Maze Dealer nearest you,
call (800) 535-0941 or (360) 833-2333 or consult our web page at www.wmaze.com

CONTENTS

Introduction	4
Owner/User Responsibility	4
Unpacking	4
Safety Instructions	4-5
General Operating Techniques	5, 10
Installation.....	6 -10
Start-Up	11-12
Operation	12
General Maintenance and Service	12
Chemical Maintenance	13
Owner Chemical Maintenance Program.....	13
Daily Chemical Maintenance	14
Optional ORP/pH Controller	14-16
Submersible Sump Pumps	17
Pump Safety Information	17
Pre-installation/Sump Pit Info	18
Pump Installation	18
Pump Operation.....	18
Pump Maintenance.....	18
Sump Pump Breakdown & Parts List.....	19
Peristaltic Metering Pump.....	20
Ozone Generator Operation	21
Ozone Generator Maintenance	21-22
Ozone Generator Testing.....	23
Ozone Generator Breakdown	24
Ozone Generator Parts List.....	25
Inlet Side - Alpha-1500 Exploded View and Parts List.....	26
Inlet Side - Alpha-3100 Exploded View and Parts List.....	27
Right Side - Alpha-1500 Exploded View and Parts List.....	28-29
Right Side - Alpha-3100 Exploded View and Parts List.....	30-31
Discharge Side, Exploded View and Parts List.....	32
Top View - Alpha 1500	33

CONTENTS

Top View - Alpha-3100.....	34
Troubleshooting	35-36
Preventative Maintenance	37
Specifications.....	38
Warranty	39

Model Number _____

Serial Number _____

Date of Purchase _____

The model and serial numbers will be found on a decal attached to the Alpha. You should record both serial number and date of purchase and keep in a safe place for future reference.

INTRODUCTION

Your owner's manual has been prepared to provide you with a simple and understandable guide for equipment operation and maintenance, based on the latest product information available at the time of printing. To keep your machine in top running condition, follow the specific maintenance and troubleshooting procedures given in this manual. When ordering parts please specify model and serial number.

This manual should be considered a permanent part of the machine and should remain with the machine if resold.

Owner/User Responsibility:

The owner and/or user must have an understanding of the manufacturer's operating instructions and warnings before using this *WATER MAZE* machine. Warning information should be emphasized and understood. If the operator is not fluent in English, the manufacturer's instructions and warnings shall be read to and discussed with the operator in the operator's native language by the purchaser/owner, making sure that the operator comprehends its contents.

The owner and/or user must study and maintain the manufacturers' instructions for future reference.

NOTE: *WATER MAZE*, Inc. reserves the right to make changes at anytime without incurring any obligations.

This manual should be considered a permanent part of the machine and should remain with it if machine is resold.


When ordering parts, please specify model and serial number.

UNPACKING

1. Alpha module with cover
2. Two 1-1/2" (3.81 cm) ball valves for recycle system
3. 1-1/2" x 16' (3.81 cm x 4.89 m) recycle hose back to pit
4. Ozone Generator
5. Operator's Manual
6. Drain Valve Manifold

Note any damage to machine or components for claims against the freight lines.

SAFETY INSTRUCTIONS



WARNING: To reduce the risk of injury, read operating instructions carefully before using.

1. Read the owner's manual thoroughly. Failure to follow the instructions could cause a malfunction of the machine and result in death, serious injury and/or property damage.



DANGER: Wire the system for correct voltage. See "Electrical" section of this manual and motor nameplate.

DANGER: Follow the wiring instructions in this manual when connecting the system to the power lines.

DANGER: All wiring must be performed by a qualified electrician.

DANGER: Meet the National Electrical Code and local codes for all wiring.

2. The installation of the machine must comply with local and/or national codes.

DANGER: Ground system before connecting to the power supply.

3. This machine, when installed, must be electrically grounded in accordance with local and/or national codes. Do not spray water near electrical components.
4. Never make adjustments on the machine while it is in operation, except for those described in this manual.



WARNING: Do not discharge concentrations of flammable or explosive fluids such as gasoline, fuel oil, kerosene, etc. into the Clarifier. Do not use in explosive atmospheres. Failure to follow this warning can produce an explosion resulting in personal injury and/or property damage.

5. Do not discharge gasoline or other volatile hydrocarbons into the Alpha. This could cause a gas vapor build-up under the lid which could become an explosive mixture.

WARNING: Wear protective eye-wear, foot protection and protective clothing.



6. Before servicing the machine, refer to all the MSDS's on the material identified in the waste stream. You must comply with all warnings and wear all protective clothing as stated on the MSDS's.

7. Protect from freezing and UV light.

These machines are designed for indoor use only. Machines must be stored indoors when not in use.

Location

The Alpha must be installed on a level surface, preferably a concrete pad near the wastewater collection sump. In cold climates the Alpha will freeze and should be located in a heated enclosure. The Alpha must be located in a heated enclosure for at least 24 hours prior to start up.

8. Protect inlet and outlet hose from vehicle traffic and sharp objects.
9. Be certain couplers on hoses have been locked before operating.
10. Before disconnecting hoses, turn machine off.
11. Inlet water temperature must not exceed 95°F/35°C.
12. When making repairs disconnect machine from electrical source.
13. The best insurance against an accident is precaution and knowledge of the equipment.
14. *WATER MAZE* is not liable for any modifications or the use of components not purchased from *WATER MAZE*.
15. The Alpha and its components will freeze, and must be located in a heated enclosure in cold climates.
16. Running the system without water will damage the pump and may void the warranty.
17. The Alpha should be installed and started up by an authorized *WATER MAZE* dealer.
18. The Alpha and its components must be protected from weather, i.e. wind, rain, direct sun, etc.

GENERAL OPERATING TECHNIQUES

The only operator adjustment to the Alpha is the valve on the inlet to the Alpha. The flow to the Alpha should be 25 GPM (94.63 L/M) or less. The recommended nominal flow rate is 10-15 GPM (37.85 - 56.78 L/M).

INSTALLATION


INSTALLATION**FRONT VIEW ALPHA-1500
(INLET END)**

Figure 1


INSTALLATION**FRONT VIEW ALPHA-3100
(INLET END)**

Figure 2

INSTALLATION SIDE VIEW ALPHA-1500




Figure 3

INSTALLATION SIDE VIEW ALPHA-3100




Figure 4

INSTALLATION

TOP VIEW ALPHA-1500




Figure 5

INSTALLATION

TOP VIEW ALPHA-3100




Figure 6

ALPHA 1500-3100 • #8.913-964.0-B

TYPICAL INSTALLATION ALPHA ONLY (discharged through sewer system)




Figure 7

INSTALLATION AUTO DISCHARGE OPTION




Figure 8

Familiarization With Alpha

The Alpha machine consists of several separate items which must be installed.

- ◆ The most obvious component is a stainless steel separator tank which is the heart of the Alpha. Take a minute to become familiar with this machine.
- ◆ Additional items furnished with the Alpha include:
 - Perforated sump pump protection/installation container.
 - Sump pump level on/off float control for pump.
 - 1-1/2" x 16' (3.81 cm x 4.89 m) recycle hose.
 - 1-1/2" (3.81 cm) ball valve for recycle system.
 - 1-1/2" x 25' (3.81 cm x 7.62 m) inlet hose with quick connect (cut to length as needed).
 - Drain valve manifold

Leveling Alpha Machine

The Alpha Machine must be set level both side to side and end to end. **This is important** to assure the machine will give you optimum performance.

Sump Pump/Level Control

- ◆ Your Alpha comes with a prepackaged perforated protection container for the sump pump. This container is designed to protect the pump from clogging and damage from debris. There is a level on/off control attached to the pump which plugs into the Alpha and then the pump plugs into the float control on the Alpha only installation.
 - Insert the Level Control Float Tree into the strain relief provided on top of the sump pump container provided.
 - Float tether length must be a minimum of 2" (5.08 cm) long.
 - The turnoff point for the float level control must be 2" (5.08 cm) above the pump container.

If you have the optional Auto Discharge Kit, refer to page 20 for proper float location.

 - The float must travel its complete arc without:
 - Water going over top of pit
 - Float touching side walls or bottom
 - Float interfering with electrical wiring, plumbing, bottom or side walls of pit, or any other object.
- ◆ Lower the sump pump container, with pump and float attached, into the sump. Check to assure the float can operate freely.
- ◆ Connect the pump hose to the inlet of the Alpha. This is a quick connect camlock fitting; be sure it is secured.

- ◆ Plug the float into the electrical outlet on the Alpha and then plug the power cord for the pump into the back of the float.
- ◆ Secure the electrical cords of the pump and the float to 1-1/2" (3.81 cm) water hose with nylon tie wraps.

Discharge

Connect the 1-1/2" (3.81 cm) discharge line to the male camlock with the other end into the proper sewer discharge (see Figure 7).

For discharge, close the recycle ball valve. During the night or on weekends and holidays, open the recycle ball valve. Add water to the collection pit until the pump starts.

Connect 1-1/2" (3.81 cm) hose to the recycle port on the Alpha (see Figure 7). The recycle line should be plumbed back to the collection pit so when the Alpha is in the recycle mode, the water in all the pits is circulated to control bacteria.

ORP/pH Controller Option

Install pH/ORP injectors and sensors per drawing on page 28 or 30. Install sensor into pipe so sensor tip is half way into pipe, touching fluid, but not touching bottom of pipe. Follow instructions on page 14 to 15 and instructions that come with controller.

Auto Discharge Option

Tie wrap the N/C and N/O floats to discharge pipe coming off sump pump. Position both floats at the same level towards the upper part of the pit.

Run float wires to electrical box on Alpha and wire according to wire diagrams.

When the water level rises and lifts the floats in the pit, the electric auto discharge valve rotates to discharge water. When the water level drops and floats fall, the electric ball valve rotates and directs water back to the pits.

Electrical

The machine, when installed, must be electrically grounded in accordance with local and/or national codes. Check for proper electrical supply. Plug the cord into a 120V 15 amp electrical outlet. It is recommended that a Ground Fault Circuit Interrupter be installed in the circuit breaker for all Wash-Water equipment.

NOTE: Always test all electrical outlets for proper voltage before plugging in any equipment.




Figure 9

START-UP

Check List Before Starting:

	Yes	No
1. Is Alpha level from side to side and end to end?	___	___
2. Is inlet hose connected to pump and Alpha?	___	___
3. Is outlet hose connected to Alpha and directed to the drain?	___	___
4. Is the voltage correct?	___	___
5. Have the pump and float been connected to the proper outlet on Alpha?	___	___
6. Is the recycle hose attached?	___	___

Start-Up:

Add water to the sump to activate the float switch.

Turn the sump pump switch on the Alpha to "ON" (see Figures 1 & 2).

Adjust the length of the Float Level Control to the desired level.

Add additional water to the sump (or Alpha directly) until the Alpha is full of water (water is exiting the outlet).

Adjust the height of the gate inside the Alpha that controls the flow into the oil skimmer. Skim off the oil with a small amount of water. The oil will stay in the oil skimmer while the water returns to the pit through the return line.

Check the machine for leaks (the machine was hydrostatically tested at the factory but may have been damaged in shipment).

Check that the machine is level side to side by observing the flow over the baffles. Shut off the inlet valve and gradually reopen it. At low flow rates when the machine is level, flow will be even across the complete top of the baffle.

Check level, end to end, by observing the water level in relation to the coalescing pack.

Check the overflow shutoff switch by manually lifting the liquid level switch (see Figures 5 & 6).

Check the recycle line to make sure the water is flowing back to the collection pit.

Start-Up Check List:

	Yes	No
1. Sump pump plugged into float level control on Alpha?	___	___
2. Sump pump float control working?	___	___
3. High level limit switch working?	___	___
4. Oil skimmer working properly?	___	___
5. Is water in Alpha level?	___	___
6. Recycle system working?	___	___
7. Level control float working?	___	___

OPERATION

After start-up, the only operational adjustment on the Alpha is the inlet flow control valve (see Figures 1 & 2). Your sump pump flowrate may exceed the Alpha's oil/water separation capacity. **Throttle the valve on the Alpha** until the incoming water is the same flow as the recycle water through the recycle line going back to the collection pit.

This will give adequate flow through the ozone injector to meter the ozone generator properly (see Figure 16). If at anytime the incoming flow is adjusted, the ozone generator must be metered again.

GENERAL MAINTENANCE AND SERVICE**Periodic Maintenance****Oil Skimmer Collection Tank**

Monitor the level of oil in the oil skimmer. Empty as needed.

Solids Removal

Settled solids are collected in the inlet solids collection chamber. The solids must be removed periodically as dictated by the dirt load coming into the machine. The procedure for removal is as follows.

- Disconnect the machine from the electrical power source.
- **Before opening the drain valve**, be sure the flow of solids is directed to the collection pit. Open each drain valve individually and remove the solids.
- Remove the vertical coalescing pack (see Figures 5 & 6 for location). To remove, lift with the nylon strap that surrounds the coalescing pack.
- After removal of the vertical coalescing pack, hose out the remaining solids in the bottom of the chamber.

- Replace the vertical coalescing pack and close valve. **NOTE:** The vertical coalescing pack can be cleaned, if desired, by washing it with a garden hose or a pressure washer.
- If the solids chamber cannot be drained back to the collection pit, you can use the *WATER MAZE* Pit Cleaner and Sludge Cart for the solids removal on the Alpha 3100. You can use a shop vac for the Alpha 1500.

Service


Check the electrical cords to assure they are safe, with no damage or cracking.

Check the inlet and outlet hoses for leaks or damage.

Oil Sheen Filter Pack

The oil sheen filter pack should be removed and the media replaced once a year or as needed (Alpha 3100).

Remove the filter pack (suitcase like filter, see Figure 6 for location) by removing the retaining bracket and lifting up with the handles on the filter, as shown below.

**Figure 10**

Slide the filter case back into the Alpha.

- The slots on top of the case should be facing the inlet.
- Push the filter firmly down and replace the retaining bracket.

NOTE: If the filter media needs servicing prior to the yearly change out, the filter can be removed and separated. Periodic cleaning of the filter media can be performed by using a hot water pressure washer. **NEVER** clean the filter with detergents as this will cause a deterioration of the media's ability to attract oil and dirt.

CHEMICAL MAINTENANCE PROGRAM

Owner Chemical Maintenance Program to Maintain Water Quality:

Daily monitoring and adjustment of *WATER MAZE* water chemistry is essential. If not monitored and controlled, the recycled water becomes chemically unbalanced, resulting in a host of problems such as algae and bacteria growth, obnoxious odors, iron discoloration and ultimately is unfit for reuse or sewer discharge.

The daily monitoring and adjustment maintenance program, if followed, will provide suitable water. The proper maintenance of the water is not complicated and depends upon a few basic principles:

1. PHYSICAL - effective filtration and recirculation of the water

Effective recirculation of the water through the collection pit, and the Alpha system is achieved only if the system is utilized often (daily 6-8 hours or more) or if the system is set to recirculate the water throughout the total system. *WATER MAZE* has provided controls and procedures to achieve continuous effective water recirculation throughout the process. The Alpha, when operated properly, achieves effective filtration and recirculation.

2. CHEMICAL - proper adjustment of alkalinity and pH

The most important factor to control and maintain is the pH of the water (i.e. the acidity or alkalinity). If the water is acidic (low pH) it will dissolve iron into solution. The presence of iron of more than 0.2 ppm will result in rusty staining of virtually anything the water comes in contact with. Alkaline water can cause cloudiness and greatly reduces the effectiveness of chlorination. Many cleaning detergents are alkaline and will make the water too alkaline. The proper pH range to maintain is 6.8 - 7.2.

Alkalinity refers to the soluble salts in the water. These include bicarbonates, carbonates, hydroxides and other alkali compounds. The water's total alkalinity controls its resistance (buffering ability) to large fluctuations in pH levels.

Another factor which should be monitored for proper water chemistry balancing is calcium hardness. The presence of too much calcium can lead to the formulation of scale.

3. BIOLOGICAL - adequate disinfection, bacteria, and odor control

Chlorination and ozonization are used to control bacteria, and odor formation. For chlorine to be effective, it must be available as free chlorine. If the proper pH and alkalinity is not maintained, or if the water contains dirt particles, the chlorine will be combined chlorine and not

be effective in the control of algae and bacteria growth. Combined chlorine has only 1/15th the strength of free chlorine.

Inadequate or improper addition of chlorine could result in bacteria growth. Once bacterial growth starts, the system must be shock treated. It is best to minimize the chances of bacteria problems.

The killing of bacteria by chlorine exists in two phases:

1. The penetration of the active germicidal principal (hypochlorous acid) into the bacterial cell and
2. The chemical combination of this ingredient with the protoplasm (the complex composition which forms the essential part of plant and animal cells). This combination is directly responsible for the death of the organism.

The activity of this germicidal effect is reduced in alkaline solutions (those with a pH greater than 7.5) and expressed as follows:

pH	% of Effectiveness
4.0	100.0
5.0	99.6
6.0	95.8
7.0	69.7
8.0	18.7
9.0	2.2
10.0	0.2

Hypochlorite when added to solutions with a pH lower than 6.0 can produce oxide which is toxic. In vehicle washing, almost all cleaning compounds are alkaline in nature. Hypochlorite will still control bacterial growth and thus smell at higher alkaline ranges, but as the table indicates, its effectiveness is reduced.

To compensate for this inhibited activity, a larger quantity of hypochlorite is used. This controls bacterial growth, but also increases operational costs.

Typical hypochlorite has a pH of approximately 11.6. This high pH increases the pH of holding tank water, making pH adjustment more difficult.

Trichloro-S-Triazine Trione is a chlorine compound which has a pH of 3.0 and when added to holding tanks aids in the reduction of tank pH levels.

Unlike hypochlorite, which is usually 15 percent chlorine and will produce sodium or calcium salts in holding tanks, these new products are 99 percent chlorine which means that if a solid "puck" of chlorine is used, the total effectiveness of the puck is superior to that of hypochlorite and no negative by-products are produced.

DAILY CHEMICAL MAINTENANCE

Step 1. Collect a water sample from the outlet of the Alpha. **NOTE:** Be sure that the water is circulating from the pit through the Alpha and back to pit.

Step 2. Using the test strips supplied, measure:

- A. The pH.
- B. The residual chlorine (systems with chlorine).
- C. The alkalinity.
- D. The calcium hardness.

Step 3. If the pH is 6.8-7.2 go to Step 4. If not, adjust the pH of the water that is recycled between the Alpha and the pit to pH 6.8-7.2. Muriatic acid or Alum can be used to lower the pH. Soda ash (sodium carbonate) or caustic soda (sodium hydroxide) can be used to raise the pH.

Adjust the pH gradually, allowing complete mixing after adding a chemical. Take a new sample, read the pH and continue to adjust gradually until the desired pH is achieved.

Step 4. The total alkalinity should be between 50-150 ppm. If the total alkalinity is too low, add sodium bicarbonate to raise it. If total alkalinity is too high, add muriatic acid to bring it within acceptable range. This will also decrease the pH. If the pH goes below 6.8, add sodium bicarbonate to increase the pH. This procedure may have to be repeated several times to get the pH and a total alkalinity into the proper range.

Step 5. The calcium hardness should not exceed 25 grains. If it is too high, some water must be removed from the system and fresh makeup water added. Alternatively, an ion exchange water softener may have to be added to the system to reduce and maintain lower calcium hardness levels.

Step 6. (Systems using a chlorinator) Free chlorine levels should be 1-2 ppm and must be maintained by adjusting the flow through the automatic chlorinator, or the regular addition of liquid chlorine. A 10-50% concentrated liquid chlorine is available. Household bleach can be used, but contains only 5% chlorine. Chlorine continually dissipates and becomes used up and the chlorine level must be adjusted daily. Remember, chlorine is most effective when the pH level is correct (7.0).

Initially, extra time is needed to achieve proper water chemistry balance. However, once achieved, it can be easily maintained in a minimum amount of time with daily monitoring and adjustment.

OPTIONAL ORP/PH DIGITAL CONTROLLER - MODEL 250

The Oxidation Reduction Potential (ORP) and pH of the water stream are controlled automatically by the digital controller. The controller receives input from the ORP sensor on the activity of the sanitizer and input from the pH sensor on the pH level of the waste stream. The level of ORP and pH being sensed and the requested levels programmed in the controller will determine if outputs from the controller are sent to the feed pumps. If sanitizer or pH adjustments are needed, the output will turn the corresponding feed pump on. This will inject the required sanitizer or pH until programmed levels are reached and the feed pump will stop.

Acid/Base Jumper

Because most systems are dealing with a high pH situation, the controller is factory set for acid feed. If you require a base feed, turn power off to entire system. Open plastic door on the controller, remove the four screws on display board, carefully pull back board and turn over. Reposition the JP14 jumper to the base position. Return board and door to original position.

Start-Up

Turn switch on right side of controller to the "ON" position. Upon power-up the controller will display "109" and then "ACD" for acid feed or "BSE" for base feed, depending on your requirements.

Feed Mode

The feed mode for the pH and sanitizer can be set to "OFF", MANUAL or AUTOMATIC. Set to Automatic. To select the desired feed mode, press [ORP] or [pH] until the corresponding LED indicator light is illuminated. There is a short delay before activation. **NOTE:** Holding the switch for more than 5 seconds resets the setpoint and calibration for [ORP] or [pH] to original factory values.

ORP Control Setpoint

The ORP setpoint is factory set at 550mV, which is recommended to maintain water quality by killing germs and bacteria. There is no need for ORP calibration.

The sanitizing concentration required to generate a desired ORP value varies with pH and overall water quality, particularly Total Dissolved Solids (TDS) concentration and organic load.

To change the ORP control setpoint:

Press [SETPOINT].

Press [ORP]; the display flashes

Use [UP] and [DOWN] arrows to adjust the ORP value

Press [SETPOINT] again to save the new value.

pH Calibration

To calibrate the pH, use a reliable, fresh test kit (Phenol Red). Note the value of the pH and compare it to the display value.

To change the pH calibration:

Press [CALIBRATION]

Press [pH]; the display flashes

Use the [UP] and [DOWN] arrows to adjust the pH value

Press the [CALIBRATION] again to save the new value.

Out-of-Range Alarms

The out-of-range alarms are factory set at 450 and 650mV for ORP and 6.5 to 7.5 for pH. If the ORP is below the low limit, the red LED alarm flashes but the sanitizer feed continues.

If the pH limits are exceeded, the red LED alarm flashes and the pH feeder continues.

To change an alarm limit:

Press [LOW LIMIT] or [HIGH LIMIT]

Use the [UP] and [DOWN] arrows to adjust the value

Press [LOW LIMIT] or [HIGH LIMIT] again.


CAUTION: Increasing the out-of-range limits may casue overfeeding of chemicals.

ORP AND PH SENSOR MAINTENANCE

The controller is virtually maintenance free. The enclosure and front panel can be cleaned with a soft cloth moistened with a mild soap and water solution or a glass cleaner. Do not use abrasives or harsh chemicals.

Sensor Cleaning/Testing

The sensor tips must be kept clean and free from chemical deposits and contamination to function properly. After saturation in the waste stream, the sensors may need to be cleaned on a weekly or monthly basis depending on the water quality and other facility-specific characteristics. Slow response and inconsistent readings are indications that the sensors are in need of cleaning.



To clean a sensor, carefully remove it from the compression fitting or holding bracket. Clean the tip of the sensor with a mild liquid detergent (Joy, etc) solution. Rinse with fresh water and soak the sensor in a mild acid solution for five minutes. Rinse with fresh water and reinstall the sensor.

To check sensor for proper operation place a small amount of white vinegar, muriatic or hydrochloric acid into a cup and place sensor probe into solution. For the pH sensor, the needle should drop. For the ORP sensor, the needle should rise.

NOTE: Only clean one sensor at a time. Sensors must stay in some kind of liquid at all times.

Sensor Replacement


For preventative maintenance it is also recommended to replace the sensors on an annual basis or as performance diminishes.

Sensor Storage

Extended exposure to atmospheric conditions will cause the sensor tips to dry out. Always remove and properly store the sensors if they are to be winterized or inactive.

Store the sensors with the original cap provided, making sure that each cap is filled with clean water. If the storage containers have been misplaced, store the sensors individually in small glass or plastic containers with clean water covering the sensor tips.

Terminal Block Wiring




B=black, W=white, G=green, R=red

TROUBLESHOOTING - ORP-pH SENSORS

All controllers are manufactured to the highest quality standards and thoroughly tested before leaving the factory. State-of-the-art designs and fabrication technology should ensure years for trouble-free operation.

PROBLEM	SOLUTION
NO LIGHTS ARE ON WITH POWER ON	Check for power going to controller.
	Check for damaged power connector.
	Check internal fuse (1A slow blo) marked F3 on control board.
ILLOGICAL pH AND ORP VALUE DISPLAYS	The sensor cable connections may be reversed. Verify that the sensor cables are properly connected to their respective BNC connectors on the controller unit.
ORP FEEDER DOES NOT ACTIVATE	Make sure the AUTO feed light for ORP is on.
	Check the ORP setpoint.
	Check ORP relay fuse (5A slow blow) marked F2 on control board.
pH FEEDER DOES NOT ACTIVATE	Verify that the acid/base feed jumper JP14 on the control board is properly set.
	Make sure the AUTO feed light for pH is on.
	Check the pH relay fuse (5A slow blow) marked F2 on control board.
pH REQUIRES FREQUENT CALIBRATION	Clean or replace the sensor as outlined in the maintenance section.
INCONSISTANT OR SLOW pH OR ORP READINGS	Verify that the sensor cables are properly connected to their respective BNC connectors and the controller unit.
	Clean or replace the sensor as outlined in the maintenance section.
	Replace the sensors if needed.
CHEMICAL FEEDER RUNS CONTINUOUSLY	Make sure the AUTO feed mode is selected.
	Verify that the chemical feeders are properly connected to their respective connectors or controller unit.

SUBMERSIBLE SUMP PUMPS



WARNING: Read instructions carefully before attempting to install, operate, or service the pump. Protect yourself and others by observing all safety information and additional instructions included with this equipment. Failure to comply with instructions could result in personal injury and/or property damage!

Retain instructions for future reference.

PUMP SAFETY INFORMATION


1. Know the pump application, limitations, and potential hazards.



WARNING: Do not use to pump high concentrations of flammable or explosive fluids such as gasoline, fuel oil, kerosene etc. Do not use in explosive atmospheres. Pump should only be used with liquids compatible with pump components materials. Failure to follow this warning can result in personal injury or property damage.

Failure to follow this warning can result in personal injury or property damage.

2. Make certain that the power source conforms to the requirements of your PUMP (115 V).
3. Disconnect power before servicing.
4. Release all pressure within the system before servicing any component.
5. Drain all liquids from the system before servicing.
6. Secure all lines before starting the pump. An unsecured line will whip, possibly causing personal injury and/or property damage.
7. Check hoses for weak or worn condition before each use, making certain that all connections are secure.
8. Periodically inspect the pump and system components. Perform routine maintenance as required (see Maintenance).
9. Personal Safety:



- a. Before servicing the machine, refer to all MSDS's on the material identified in the waste stream. You must comply with all warnings and wear all protective clothing stated on the MSDS's.

- b. Keep work area clean, uncluttered and properly lighted — replace all unused equipment.
- c. Keep visitors at a safe distance from work area.
- d. Make workshop childproof — with padlocks, master switches, and by removing starter keys.
10. When wiring an electrically driven pump, follow all electrical and safety codes, as well as the most recent National Electrical Code (NEC) and the Occupational Safety and Health Act (OSHA).



DANGER: Risk of electric shock.

This equipment is only for use on 115 volt (single phase) and is equipped with an approved 3-prong conductor cord and 3-prong grounding-type plug (as shown in Figures 1 & 2) for your protection against shock hazards. It should be plugged directly into a properly installed and grounded 3-prong grounding-type receptacle.

It is recommended that a Ground Fault Circuit Interrupter be installed in the circuit breaker for all Wash Water equipment.

11. All wiring must be performed by a qualified electrician.
12. Make certain that the power source conforms to the requirements of your equipment.
13. Protect the electrical cord from sharp objects, hot surfaces, oil, and chemicals. Avoid kinking the cord. Replace or repair damaged or worn cords immediately.
14. Use wire of adequate size to minimize the voltage drop at the motor.
15. Disconnect power before servicing a motor or its load. If the power disconnected is out-of-sight, lock it in the open position and tag it to prevent unexpected application of power.
16. Do not touch an operating motor. Modern motors are designed to operate at high temperatures.
17. Do not handle a pump or pump motor with wet hands or when standing on a wet or damp surface, or in water.
18. The pump motor is equipped with an automatic resetting thermal protector and may restart unexpectedly. Protector tripping is an indication of motor overloading as a result of operating the pump at low heads (low discharge restriction), excessively high or low voltage, inadequate wiring, incorrect motor connections, or a defective motor or pump.
19. DO NOT run the pump without water. This will damage the pump.

PRE-INSTALLATION SUMP PIT INFORMATION

(For Sump Pit Installation Only)

The sump pump can be installed in a sump pit with a minimum diameter of 18" (45.72 cm) and a depth of 24" (60.96 cm). (Pit dimensions less than these will cause rapid cycling and shortened pump life). It is recommended that the sump pit be no smaller than 2' x 2' x 3' (.61 m x .61 m .91 m). The sump pit may be constructed of tile, concrete, steel, fiberglass or plastic. Check local codes for approved materials. Make sure there are no small stones, gravel, sand, dirt silt, etc. that may clog or damage the pump and/or pump seal, and cause pump failure. If there are stones or gravel, clean these out before installing the pump. Test pump for proper operation (see Operation) before installing sump pit cover. A sump pit cover will prevent debris from possibly clogging or damaging the pump. It will also prevent persons from falling in and causing injury to themselves. If an existing pit is being used, it must be thoroughly cleaned before installation.

SUMP PUMP INSTALLATION

WARNING: *This sump pump is not designed for use in septic tanks or underground vaults to handle raw sewage or effluents. It should never be used in hazardous or explosive locations. Do not use power cord to lift motor. Always use the handle.*

1. The sump pump should not be suspended by means of the discharge pipe or power cord. Instead it should be resting on a solid foundation in the bottom of the pit. Clean the sump pit of small stones, gravel, sand, dirt, silt, etc., which could clog or damage pump, pump seal, and cause pump failure.
2. The sump pump is designed for 115 V, 60 HZ operation and requires a circuit of 15 amperes. It is supplied with a 3-wire cord set with a grounding-type plug for use in a 3-wire, grounded outlet. For safety, the pump should always be electrically grounded to a suitable electrical ground such as a grounded water pipe or a properly grounded metallic raceway, or ground wire system.
3. After all piping and controls have been installed, the machine is ready for operation.

PUMP OPERATION

WARNING: *Do not touch sump pump, pump motor, water or discharge piping when the pump is connected to electrical power. Do not handle pump or pump motor with wet hands or when standing on wet or damp surface, or in water. Never touch the sump pump or discharge piping when machine is operating or fails to operate. Always disconnect the pump cord (power) before handling.*

1. The shaft seal depends on water for lubrication. Do not operate the pump unless it is submerged in water. Dry running (pump not pumping water) will cause seal damage and eventual pump failure.
2. The motor is equipped with an automatic reset thermal protector. This means if the temperature in the motor should rise unduly, the switch will cut off all power before damage can be done to the motor. When the motor has cooled sufficiently, the switch will reset automatically and restart the motor. If the protector trips repeatedly (cycling on protector) the pump should be removed and checked for the cause of difficulty. Low voltage, long extension cords, clogged impeller, very low head or lift, etc., can cause cycling. Cycling on the protector eventually causes motor burnout.


PUMP MAINTENANCE

WARNING: *Before attempting to service, disconnect power from machine. Do not handle pump with wet hands or when standing on wet or damp surfaces or when in water. Failure to follow precaution can result in personal injury and/or property damage.*

NOTE: This is a difficult pump to repair, therefore only qualified electricians or servicemen should attempt to repair this machine. Improper repair and/or assembly can cause an electrical shock hazard.

Follow recommendation from your pump manufacturer.

SUMP PUMP ASSEMBLY & PARTS LIST




ITEM	PART NO.	DESCRIPTION	QTY
1	8.706-362.0	▲ Pipe, CPVC S40, 1/2" (1.27 cm) /ft.	3.5
2	8.709-112.0	▲ C-Clamp, Plastic, 5/16" (.79 cm)	2
3	8.716-144.0	Switch, Float, N/O, w/Plug	1
4	8.711-944.0	▲ Lid Only, 6.5 gal., (24.60 L) Reike Sr.	1
5	8.711-943.0	Pail Only, 6.5 gal., (24.60 L) Polly White	1

ITEM	PART NO.	DESCRIPTION	QTY
6	9.802-511.0	Wrap, Ty, 11 Black	5
7		Sump Pump, Not Supplied	1
8	8.670-187.0	Switch, Float N/O (optional with auto discharge)	1
9	8.716-143.0	Switch, Float N/C (optional with auto discharge)	1
		▲ Not Shown	

SERIES VARIABLE SPEED**PERISTALTIC METERING PUMP MODELS VSP 20****#5-2360 TECHNICAL INFORMATION**

Feed Rate	2.6 - 20 GPD
Tubing Size	7/16" O.D. x 1/4" I.D.
Dimensions	5" H x 6-1/4" W x 7" D
Standard Accessories Included	Head Tubing Injection Fitting with Check Valve Strainer Polyethylene Tubing (1/4 O.D. x 15) Tubing Sleeve (for strainer connection)
Electrical Rating	115V 50/60Hz
Materials:	
Pump Head	Polycarbonate
Pump Head Tubing	Special Synthetic Rubber
Strainer and Injection Point Fitting	PVC
Maximum System Pressure	25 psi (maximum allowed at injection fitting)

INSTALLATION DIAGRAM**Figure 15**

ULTRAVIOLET LIGHT COMPLIANCE

Ultraviolet Light Safety Requirements

The device used in this product is a Class 1 certified ozone generator product. Operating this product outside specifications or altering its original design may result in hazardous radiation exposure, and may be considered an act of modifying or new manufacturing of a laser product under U.S. regulations contained in 21CFR Chapter 1, subchapter J.



- CAUTION:** Avoid exposure to direct or strongly reflected germicidal ultraviolet rays. DO NOT STARE INTO BEAM.
- DANGER:** Ultraviolet radiation. Disconnect Power Before Replacing Lamp.
- DANGER:** Connect only to a circuit that is protected by Ground Fault Circuit Interrupt (GFCI).

Instructions for disposing of your UV Light Tube

- Do not break a UV Light Tube. Keep all tubes whole if possible. If a UV Light Tube is accidentally broken, wear gloves while picking up the pieces, and carefully dispose of them in a trash bag. Wipe the area with a wet wipe, and put the wet wipe in the same trash bag. Place the trash bag with broken pieces inside another trash bag. Mark the bag with a sign labeled, "Broken Mercury Light Bulb".
- Remove the UV Light Tube from the Ozone Generator. Place the used tube in the trash bag, and place that bag inside another trash bag. Seal the openings and then tape a slip of paper on the outer bag labeled, "Mercury Light Bulb."
- Take the used and /or broken mercury tube to your nearest recycling bin for mercury light bulbs..or take this tube to a state-approved recycling center.

OZONE GENERATOR OPERATION

The indicator light on the Ozone Generator will have a dim green light or no light if the machine is working. It will have a bright green light if the machine has a malfunction.

Setting the Ozone Generator

An SCFH (Standard Cubic Feet per Hour) gauge is used to accurately measure the amount of air flowing through the ozone delivery line, or in other words, the amount of ozone being injected into the water

- With the pump running, disconnect the tubing from the ozone check valve and connect the tubing to the bottom fitting on the gauge. This tube is from the ozone generator.
- While holding the gauge vertically, connect the tubing from the top of the gauge to the ozone injector and read the amount indicated on the gauge.
NOTE: You are measuring suction, so make sure tubing is attached properly.
- Begin adjusting metering valve until a 10 SCFH flow for the Series 101 is achieved on the SCFH gauge.
NOTE: Series 200 is set at 20 SCFH and Series 400 at 40 SCFH. The Alpha machine comes with series 101 standards.
- Reconnect tubing to the ozone check valve.




Figure 16

OZONE GENERATOR MAINTENANCE

CAUTION: *Never look at the unshielded ozone lamp while operating the machine. This lamp can cause severe eye and skin damage. There is a green indicator light that will turn bright green if there is a problem. It will be OFF to DIM under normal running conditions.*

Lamp: The lamp has a 9,000 hour life expectancy.

Testing the Lamps:

To test the ozone lamp use a voltmeter set on ohms. First remove the ozone cover and unplug the lamp plug from the ozone lamp. **NOTE:** There are two filaments, an upper and a lower, inside the lamp. Place one of the voltmeter leads on one of the lamp prongs and with the other lead, touch all of the three remaining prongs. If continuity is not achieved, replace the ozone lamp (Part #8.716-600.0). You should get continuity from two prongs for the upper filament and from the other two prongs for the lower filament (see diagram on page 25).


To test the ballast, use a voltmeter set on the correct voltage (120V). Place one of the voltmeter leads into the lamp plug where the white wire goes into it and plug the other voltmeter lead into the lamp plug where the blue wire goes into it. If no voltage is present, replace the ballast (Part #8.716-590.0 - 120V). If the lamp has continuity and the voltage is good on the ballast but the lamp still will not come on, there is a problem with the starter inside the ballast and the ballast must be replaced.

Replacing the Lamps:

Replacement lamps are available from your Water Maze Dealer should one be needed. Simply turn off the power, remove the two screws on the power pack cover and remove the cover. Disconnect the plug on the end of the ozone lamp. Now, loosen the lamp holder locking ring from around the end of the lamp by turning it counter clockwise and remove it. Remove the lamp by grabbing the rubber bushing around the end of the lamp and pulling it straight out. Remove the rubber bushing from the lamp and install it on your new lamp, making sure the outer edge of the bushing is flush with the outer edge of the silver end cap on the lamp. Now, slide the lamp back into the reaction chamber. The lamp holder may now be reinstalled and tightened. Reinstall the plug onto the lamp and replace the pack cover.

CAUTION: *Keep the lamp free of fingerprints and dust particles. Handle only the metal end caps. You can clean the lamp with rubbing alcohol and a soft cloth. A dirty lamp will not allow maximum ozone output.*

OZONE GENERATOR TESTING



SPECIFICATIONS

Energy required 110V: 105 VAC MIN., 125VAC MAX., .800 AMP


Power Consumption: 20 Watts

Average Lamp Life: 9,000 Hours

Lamp Wavelength: 185 nm

Dimensions: 10½" x 23½" x 8" (26.67 cm x 59.69 cm x 20.32 cm)


OZONE GENERATOR PARTS BREAKDOWN



OZONE GENERATOR • SERIES 101 PARTS LIST

ITEM	PART NO.	DESCRIPTION	QTY
1	8.913-351.0	Ozone Box, Back, 200	1
2	8.913-356.0	Ozone Box, Front, 200	1
3	9.802-455.0	Light, Indicator, Green, 125V	2
4	9.802-523.0	Locknut, 3/4" (19.05 mm) Conduit	2
5	8.716-583.0	Connector, Aluminum Cord SCH1037	2
6	8.716-592.0	Connector, 4 Pin Plug	2
7	8.716-600.0	Lamp, Ozone Replacement	2
8	8.707-355.0	Ozone Check Valve	1
9	9.802-696.0	Nut, 10/32" (7.94 mm) NF ST ST KEP	10
10	8.706-570.0	Locknut, 3/8" (9.53 mm) Nylon	2
11	8.706-585.0	Connector, 3/8" x 3/8" (9.53 mm x 9.53 mm), Male Elbow (Kynar)	2
12	8.706-594.0	Tee, 3/8" (9.53 mm) (Kynar)	1
13	8.706-733.0	Bushing, 1/2" (12.7 mm) Snap	1
14	8.711-733.0	Tubing, 3/8" x 1/2" (9.53 mm x 12.7 mm) Clear Vinyl	7 ft.
15	9.802-423.0	Cord, Service, SEO, 16/3 (30.48)	9 ft.

ITEM	PART NO.	DESCRIPTION	QTY
16	8.716-051.0	Switch, Curvette 120V & 220V	1
17	9.802-514.0	Strain Relief, LT, Str 1/2" NPT, .23-.45D	1
18	8.706-544.0	Cushion, 1/2" x 8-3/4" x 5-3/4" (12.7 mm x 22.23 cm x 14.61 cm) 200	1
19	8.913-352.0	Ozone Box , Top, 200	1
20	8.913-353.0	Ozone Box, Bottom, 200	1
21	8.716-590.0	Ballast, 120/230 Volt Ozone Generator	2
22	9.802-698.0	Screw, 10-32" x 1/2" Slot Pan MS	10
23	8.718-959.0	Washer, #10 Flat, SS	11
24	8.718-940.0	Screw, #10 x 3/4" HWH TEK SS	8
25	8.900-455.0	Label, Ozone Generator Operating Instructions	1


INLET SIDE (Front)
ALPHA-1500

ITEM	PART NO.	DESCRIPTION	QTY
1	8.707-300.0	Valve, 1" PVC Ball Check	1
2	8.706-485.0	Bulkhead, Cycl. 1-1/2" (3.81 cm) PVC SP 1023	6
	8.706-404.0	Bushing, 1-1/2" x 1" (5.08 mm x 3.81 cm) MT x FT, PVC 80	1
3	8.706-423.0	Hanger, Pipe, 1" (3.81 cm) Clic #32	1
4	8.707-355.0	Valve, 3/8" Tubing Check S-46-01-0008	1
5	8.711-733.0	Tubing, 3/8" x 1/2" Clear Vinyl /ft. (30.48 cm)	3
6	8.905-707.0	Ozone Generator, Series 101 (120V)	1
7	9.802-453.0	Switch, Curvette, 120V & 220V	2
8	8.716-257.0	▲ Relay, Power Omron G4B112T FDCUSRPAC 120	1
	9.802-475.0	Box, Plastic, 8" x 8" x 4" (20.32 cm x 20.32 cm x 10.16 cm), w/Lid	1
	8.913-330.0	Panel Control, Alpha	1

ITEM	PART NO.	DESCRIPTION	QTY
9	9.802-514.0	Strain Relief	2
10	8.716-319.0	Receptacle, Duplex, 115V	1
	8.716-320.0	Cover, SC, Duplex, 3780SC	1
11	8.913-335.0	Tank Assy Welded, Alpha 1500 Stainless Steel	1
12	8.706-485.0	Bulkhead, Clyc, 1-1/2" (3.81 cm) SP1023	1
13	8.716-572.0	Connector, Strain Relief, TB2522	1
14	8.716-307.0	Plug Male, 115V, 15 amp Heavy Duty	1
15	8.707-343.0	Valve Gate, PVC 1" (2.54 cm), FIPT x FIPT	1
16	8.706-586.0	Connector, Male (Poly) 3/8" x 1/4" (9.53 mm x 6.35 mm)	1
17	8.707-321.0	Valve, Ozone Metering, Plastic	1
18	8.706-587.0	Nipple, Hex Red, 1/2" x 1/4" (12.7 mm x 6.35 mm) (Poly)	1
19	8.709-431.0	Injector, Ozone	1
20	8.707-169.0	Camlock, 1-1/2" (3.81 cm) Male x MPT	1

▲ Not Shown

INLET SIDE (FRONT) ALPHA-3100




ITEM	PART NO.	DESCRIPTION	QTY
	8.906-751.0	Alpha Inlet Manifold Assy, 1-1/2" (3.81 cm)	1
1	8.707-169.0	Camlock 1-1/2" (3.81 cm) Male x MPT	1
2	8.709-431.0	Injector, Ozone	1
3	8.707-344.0	Valve, Gate, PVC, 1-1/2" (3.81 cm) Slip x Slip	1
4	8.707-297.0	Valve, 1-1/2" (3.81 cm) PVC, Ball Check	1
5	8.706-424.0	Nipple, PVC Close, 1-1/2" (3.81 cm)	1
6	8.706-485.0	Bulkhead, Clyc. 1-1/2" (3.81 cm) PVC SP1023	1
7	8.706-372.0	Elbow, PVC 80, 1-1/2" (3.81 cm) Slip x FIPT	1
8	8.716-307.0	Plug, Male 115V, 15 amp Heavy Duty	1
9	8.716-095.0	Light, Indicator, Red, 125V	1
10	8.905-707.0	Ozone Generator, Series 101 (120V)	1
	8.716-600.0	▲ Lamp, S-1200 Ozone Replacement	1
	8.716-592.0	▲ Connector, 4 Pin Plug	1
10	8.716-588.0	▲ Ballast, 120V, Ozone Generator	1

ITEM	PART NO.	DESCRIPTION	QTY
11	8.707-321.0	Valve, Ozone Metering, Plastic	1
12	8.706-587.0	Nipple, Hex Red, 1/2" x 1/4" (12.7 mm x 6.25 mm) Poly	1
13	9.802-453.0	Switch, Curvette, 120V & 220V	2
14	9.802-475.0	Box, Plastic, 8" x 8" x 4" (20.32 cm x 20.32 cm x 10.16 cm) , w/Lid	1
	8.913-330.0	Panel Control, Alpha	1
	8.900-518.0	Label, Alpha Control Panel	1
	8.716-572.0	Connector, Strain Relief, TB2522	1
	8.716-257.0	▲ Relay, Power Omron	1
15	9.802-514.0	Strain Relief	2
16	8.716-319.0	Receptacle, Duplex, 115V	1
	8.716-320.0	Cover, SC, Duplex, 3780-SC	1
17	8.711-733.0	Tubing, 3/8" x 1-1/2" (9.53 mm x 3.81 cm) Black Vinyl /ft. (30.48 cm)	3
18	8.707-355.0	Valve 3/8" (9.53 mm) Tubing Check	1
19	8.912-198.0	Tank Only, Alpha-3100, Stainless Steel	1
20	8.706-586.0	Connector, Male (Poly) 3/8" x 1/4" (9.53 mm x 6.25 mm)	1

▲ Not Shown

RIGHT SIDE VIEW
ALPHA 1500




RIGHT SIDE VIEW ALPHA 1500 PARTS LIST

ITEM	PART NO.	DESCRIPTION	QTY	ITEM	PART NO.	DESCRIPTION	QTY
1	8.706-469.0	Union, 1-1/2" (3.81 cm) S x S	2	20	8.706-448.0	Adapter, 1-1/2" FT x 1-1/2" Slip (3.81 cm x 3.81 cm)	2
2	8.706-428.0	Tee, 1-1/2" (3.81 cm) S x S x T	2	21	8.706-379.0	Elbow, 1-1/2" Slip x Slip x Slip, PVC 80, 45°	4
3	8.706-372.0	▲ Elbow, 1-1/2" (3.81 cm) SLIP x FIPT, PVC 80, 90°	1	22	8.706-407.0	Bushing, 1/2" x 1/4" MT x FT	2
4	8.707-021.0	Push-On Barb 3/4" x 3/4" (19.05 mm x 19.05 mm) MPT	1	23	8.706-406.0	Bushing, 1-1/2" x 1/2" SPG x FT	4
5	8.706-424.0	Nipple, PVC 80 1-1/2" (3.81 cm)	1	24	8.716-990.0	Controller Only, CH250 ORP/pH, Digital	1
6	8.913-338.0	▲ Slide, Stainless	1	25	8.715-378.0	Pump, Metering, 24V	2
	8.913-337.0	▲ Trough Assembly	1	26	8.716-984.0	Tubing, 15' Roll	2
7	8.706-377.0	Elbow, 90° 3/4" (19.05 mm) FIPT x FIPT	1		8.711-736.0	▲ Tube	2 ft.
8	9.802-084.0	Float Tank	1	27	8.716-905.0	Sensor, pH	1
9	9.802-052.0	Bulkhead, 3/4" (19.05 mm) Plastic	1		8.716-906.0	▲ Sensor, ORP	1
10	8.750-743.0	▲ Bulkhead, 1/2" Polypro	2	28	8.913-307.0	Bracket, pH/ORP Controller	1
	8.706-387.0	▲ Plug, 1/2" MIPT, PVC 80	1	29	9.802-475.0	Box, Plastic, 8 x 8 x 4	1
11	8.706-485.0	Bulkhead, Cyc. 1-1/2" (3.81 cm) SP1023	4	30	8.716-319.0	Receptacle, Duplex, 115V	1
	8.706-492.0	▲ Nipple, PVC 80, 1-1/2" x 2-1/2" (3.81 cm x 6.35 cm)	1	31	8.716-257.0	Relay, Power Omron	1
12	8.706-394.0	Plug, 1-1/2" (3.81 cm), PVC 80	3	32	9.802-453.0	Switch, Curvette	1
13	8.707-359.0	Ball Valve, 3/4" (19.05 mm) PVC	1	33	9.802-515.0	Strain Relief	2
14	8.707-361.0	Valve, 1-1/2" S x S	2	34	9.802-428.0	Cord, Electric, 12/3	15ft
15	8.707-169.0	Adapter, 1-1/2" Male x 1-1/2" Male Thrd Camlock (3.81 cm x 3.81 cm)	1	35	8.900-518.0	Label, Control Panel	1
16	8.706-426.0	Tee, 1-1/2" S x S x S	2	36	9.802-553.0	Transformer, Micron, 120/240V-24V, .050 KVA	1
17	8.706-485.0	Bulkhead, Cyc, 1-1/2" (3.81 cm) SP 1023	6	37	9.803-663.0	Fuse, KTK-R2, 600V	2
18	8.716-986.0	Injector	2	38	9.803-977.0	Fuse, 2-1/2 Amp, 250V	1
19	9.802-261.0	Hose, Push-On, 3/4" (19.05 mm) (30.48 cm)	1.5 ft.	39	8.716-970.0	Compression Fitting	2
				40	8.940-055.0	Label, Assembled In USA	1

▲ Not Shown

RIGHT SIDE VIEW
ALPHA-3100



RIGHT SIDE VIEW ALPHA-3100 EXPLODED VIEW


ITEM	PART NO.	DESCRIPTION	QTY
1	8.706-469.0	Union, 1-1/2" (3.81 cm) S x S	2
2	8.706-428.0	Tee 1-1/2" (3.81 cm) S x S x T	2
3	8.706-372.0	▲ Elbow, 1-1/2" (3.81 cm) S x FIPT	1
4	8.707-021.0	Push-On Barb, 3/4" x 3/4" (19.05 mm x 19.05 mm) MPT	1
5	8.706-424.0	Nipple, PVC 80 1-1/2" (3.81 cm)	1
6	8.913-338.0	▲ Slide, Stainless	1
	8.913-337.0	▲ Through Assembly	1
	8.706-705.0	▲ Gasket, Oil Skimmer	1
7	8.706-377.0	Elbow, 90° 3/4" (19.05 mm) FIPT x FIPT	1
8	9.802-084.0	Float Tank	1
9	9.802-052.0	Bulkhead, 3/4" (19.05 mm) Plastic	1
10	8.706-369.0	Nipple, Close 3/4" (19.05 mm)	1
11	8.706-424.0	Nipple, PVC 80, 1-1/2" Close (3.81 cm)	1
12	8.750-743.0	▲ Bulkhead Fitting, 1/2" Polypro	1
13	8.707-339.0	Valve, 3/4" (19.05 mm) PVC Ball	1
14	8.707-361.0	Valve, 1-1/2" (3.81 cm) S x S	2
15	8.707-169.0	Adapter, 1-1/2" Male x 1-1/2" Male Thrd Camlock (3.81 cm x 3.81 cm)	2
16	8.706-426.0	Tee, 1-1/2" (3.81 cm) S x S x S	2
17	8.706-485.0	Bulkhead, Cyc, 1-1/2" (3.81 cm) SP 1026	6
18	8.706-394.0	Plug, 1-1/2" (3.81 cm) PVC 80	4
19	9.802-261.0	Hose, Push-On, 3/4" (19.05 mm) (30.48 cm)	1.5 ft.

ITEM	PART NO.	DESCRIPTION	QTY
20	8.706-379.0	Elbow, 1-1/2" Slip x Slip, PVC 80, 45°	4
21	8.706-407.0	Bushing, 1/2" x 1/4" MT x FT	2
22	8.706-406.0	Bushing, 1-1/2" x 1/2" SPG x FT	4
23	8.716-905.0	Sensor, pH	1
24	8.716-906.0	Sensor ORP	1
25	66-8800172	Injector, IPF	2
26	8.716-990.0	Controller Only, CH250 ORP/pH Digital	1
27	8.715-378.0	Pump, Metering, 24V	2
28	8.716-984.0	Tubing, 15' Roll	2
29	9.802-475.0	Box, Plastic, 8" x 8" x 4"	1
30	8.716-319.0	Receptacle, Duplex, 115V	1
31	8.716-257.0	Relay, Power Omron	1
32	9.802-453.0	Switch, Curvette	1
33	9.802-515.0	Strain Relief	2
34	9.802-428.0	Cord, Electric, 12/3	15 ft.
35	8.900-518.0	Label, Control Panel	1
36	9.802-553.0	Transformer, Micron, 120/240V-24V, .050 KVA	1
37	9.803-663.0	Fuse, KTK-R2, 600V	2
38	9.803-977.0	Fuse, 2-1/2 Amp, 250V	1
39	8.711-736.0	Tube	2 ft.
40	8.716-970.0	Compression Fitting	2
41	8.940-055.0	Label, Assembled In USA	1

▲ Not Shown


DISCHARGE SIDE

ALL MODELS



ITEM	PART NO.	DESCRIPTION	QTY
1	8.706-387.0	Plug, 1/2" (12.7 mm) MIPT PVC 80	2
	8.750-743.0	Bulkhead, 1/2" Polypro	2
2	8.707-169.0	Camlock, 1-1/2" (3.81 cm) Male x MPT	2
3	8.707-361.0	Valve Ball, PVC 1-1/2" (3.81 cm) S x S	2
4	8.706-424.0	Nipple, PVC 80, 1-1/2" (3.81 cm) Close	1
5	8.706-394.0	Plug, 1-1/2" (3.81 cm) PVC 80	4
	8.706-485.0	Bulkhead, Cyc. 1-1/2" (3.81 cm) SP 1023	6


TOP VIEW ALPHA-1500



ITEM	PART NO.	DESCRIPTION	QTY
1	8.905-707.0	Ozone Generator Series 101 (120v)	1
	8.716-600.0	▲ Lamp, S-1200 Ozone Replacement	1
	8.716-592.0	▲ Connector, 4 Pin Plug	1
	8.716-588.0	▲ Ballast, 120v, Ozone Generator	1
2	8.706-671.0	Grid, Horizontal Coalescing Alpha-1500	16
	8.706-675.0	Grid, Horizontal Coalescing Alpha-500	16
3	8.709-339.0	Strap, Coalescing Grid, 112" (284.48 cm) Alpha-500	1
		Alpha-1500	2
4	8.913-304.0	Retainer, Coalescing Pack, SS Alpha	1
5	8.716-632.0	Switch, Liquid Level	1

ITEM	PART NO.	DESCRIPTION	QTY
6	8.903-588.0	Oil Skimmer Assembly	1
7	8.707-361.0	Valve, Ball, 1-1/2" (3.81 cm) S x S	2
8	8.706-668.0	Grid, Vertical Coalescing Alpha	4
9	8.709-338.0	Strap Coalescing Grid, 60" (152.4 cm)	1
10	8.706-374.0	Elbow, 1.5" SxS PVC 80 90°	2
11	8.706-469.0	Union, 1.5" SxS, PVC 80	5
	8.706-441.0	▲ Adaptor, 1.5" SxMT	5
12	8.707-361.0	Valve 1.5" S80 PVC SxS	5
13	8.706-426.0	Tee, 1.5" SxSxS, PVC 80	4

▲ Not Shown

TOP VIEW
ALPHA-3100

ITEM	PART NO.	DESCRIPTION	QTY
1	8.709-338.0	Strap, Coalescing Grid, 60"	1
2	8.706-666.0	Grid Vertical Coalescing	9
3	8.706-671.0	Grid Horizontal Coalescing	36
4	8.709-339.0	▲ Strap, Coalescing Grid 112" (284.48 cm)	2
5	8.913-301.0	Retainer, Coalescing Pack, SS	3
6	8.716-632.0	Switch, Liquid Level	1
7	8.706-672.0	Suitcase, Pom Pom Filters	1
	8.706-673.0	▲ Pom Pom, Sorbaid	2
8	8.903-588.0	Oil Skimmer Assembly	1

ITEM	PART NO.	DESCRIPTION	QTY
8	8.913-337.0	Skimmer Trough	1
	8.706-705.0	Gasket, Oil Wheel	1
	8.910-260.0	Face Plate Assembly	1
9	8.706-374.0	Elbow, 1.5" SxS, PVC 80	1
10	8.706-469.0	Union, 1.5" SxS, PVC 80	4
	8.706-441.0	▲ Adaptor, 1.5" SxMT	4
11	8.707-361.0	Valve 1.5" S 80 SxS	4
12	8.706-426.0	Tee, 1.5" SxSxS, PVC 80	3

▲ Not Shown

TROUBLESHOOTING

PROBLEM	POSSIBLE CAUSE	SOLUTION
NO FLOW OF WATER INTO ALPHA	Control switch not in "ON" position	Turn switch to "ON" position.
	Water in sump not high enough to activate level switch	Lift float level switch and see if pump turns on.
	Alpha not plugged in	Plug in Alpha.
	High level limit switch shut off	Check on/off functioning. Adjust, repair or replace.
	Debris in pump impeller	Unplug pump and remove from container. Check impeller. Clean/repair.
	Flow control valve in "OFF" position	Open valve.
	Dirt collection chamber full	Drain and clean.
	Dirt lodged in control valve or check valve	Clean as needed.
	Frozen water in lines or valves	Thaw out with warm water.
EXCESSIVE WATER FLOWING INTO OIL SKIMMER	Tank not level end to end or side to side	Level tank.
	High level limit switch not functioning	Check ON/OFF functioning. Adjust, repair or replace.
	Water coming into Alpha faster than machine is rated for	Adjust flow control valve.
	Oil sheen filter pack plugged (Alpha 3100)	Remove and clean.
	Discharge line plugged or valve closed	Remove obstruction or open valve.
OIL ON TOP OF WATER IN EXIT CHAMBER	Oil sheen filter pack not firmly in place (Alpha 3100)	Push down on filter firmly to lock in place.
	Oil sheen filter pack dirty (Alpha 3100)	Remove and replace/clean media.

TROUBLESHOOTING

PROBLEM	POSSIBLE CAUSE	SOLUTION
PUMP WON'T START	Tripped breaker	Reset breaker.
	Low line voltage	If voltage under recommended minimum, check size of wiring from main switch on property. If OK, contact power company.
	Defective motor	Replace motor.
	Pump filled with mud or debris	Remove pump base and clean out mud or debris.
PUMP STARTS AND STOPS TOO OFTEN	Low line voltage	If voltage under recommended minimum, check size of wiring from main switch on property. If OK, contact power company.
	Long extension cords	Shorten extension cord.
	Clogged impeller	Remove housing, unclog.
	Faulty motor protector	Replace pump.
	Very low head or lift	Increase head or lift.
	Back flow of water from long discharge line	Add check valve as close as possible to pump (see installation).
	Sump pit too small	Increase size of pit.
PUMP WON'T SHUT OFF	Defective float switch	Replace.
PUMP OPERATED BUT DELIVERS LITTLE OR NO WATER	Low line voltage	If voltage under recommended minimum, check size of wiring from main switch on property. If OK, contact power company.
	Fouled sediment screen	Clean, repair or replace as needed.
	Worn or defective pump parts or plugged impeller	Replace worn parts or entire pump. Clean parts if required.
	Pump air locked	Turn pump "On-Off" several times. Fill hose manually with water.
	Wear plate and impeller worn	Check and replace if needed.

PREVENTATIVE MAINTENANCE

This Alpha machine was produced with the best available materials and quality craftsmanship. However, you as the owner have certain responsibilities for the correct care of the equipment. Attention to regular preventative maintenance procedures will assist in preserving the performance of your equipment. Contact your WATER MAZE, Inc. dealer for maintenance. Regular preventative maintenance will add many hours to the life of your pressure washer. Perform maintenance more often under severe conditions.

MAINTENANCE SCHEDULE	
System Flow Rate - Check visually Alpha 3100 - Completely covering exit pipe All Units: Make sure the overflow switch in the coalescing chamber is not "cycling"	Daily
Exit Pipe - Check for obstructions	Daily
Ozone Generator - Check indicator light. (light "on" indicates malfunction)	Daily
Check control panel to make sure switches are on and voltage is connected to unit	Daily
Check all plumbing for leaks	Daily
Check water chemistry and make needed adjustments	Daily
Coalescing Chamber - Check for solids accumulation. Clean out if over 4" of solids	Weekly
Ozone Generator - Check air flow. Set to 10 SCFM	Monthly
Inlet (first) Chamber - Check for solids accumulation. Clean as required	Monthly
Suck sludge and debris from pits	Monthly
Check sump pump and if necessary clean out dirt and debris	Monthly
Clean dirt or grease from float	Monthly
Check float wires for cuts or frays	Monthly
Coalescing Plates - Remove and inspect. Clean with warm water - no detergents. When reinstalling make sure pack fits snug to bottom	Monthly
Oil Skimmer - Drain off oil layer if over 1/2" (12.7 mm) thick. Close drain when done. Check input flow to skimmer. Adjust "slot" height for flow rate of "just a trickle"	Monthly or as needed
Alpha 3100 Only Remove "suitcase filter". Open, remove and rinse "pom pom filters." Use warm water - no detergents. Reassemble and install	Quarterly or as needed
Ozone Generator Bulb - Replace	As needed

SPECIFICATIONS

MODEL		ALPHA 1500	ALPHA 3100
FLOW RANGE	GPM (LPM)	0-15 (56.78)	0-30 (113.55)
HOLDING CAPACITY	GAL (LTR)	125 (473.13)	250 (946.25)
ELECTRICAL	V/AMP	120/12	120/12
COALESCING PACK		500 sq.ft. (152.35)	1000 sq.ft. (304.79)
OZONATOR		Series 200	Series 200
SUMP PUMP (RECOMMENDED)		1/2 HP, 120V (.37 kw)	1/2 HP, 120V (.37 kw)
OIL SKIMMER		Manual	Manual
TANK MATERIAL		Stainless Steel	Stainless Steel
DIMENSIONS	L/W/H IN (CM)	80/36/31" (203.2/91.44/78.74)	83/48/32" (210.82/121.92/81.28)
MACHINE ONLY WEIGHT	LBS (KG)	325 (147.73)	490 (222.73)
SHIPPING WEIGHT	LBS (KG)	545 (247.73)	760 (345.45)



LIMITED NEW PRODUCT WARRANTY WASH WATER / WATER TREATMENT SYSTEMS

WHAT THIS WARRANTY COVERS

All *WATER MAZE* water treatment systems are warranted by to the original purchaser to be free from defects in materials and workmanship under normal use, for the periods specified below. This Limited Warranty, subject to the exclusions shown below, is calculated from the date of the original purchase, and applies to the original components only. Any parts replaced under this warranty will assume the remainder of the part's warranty period. A 60 day grace period will be given for installation.

ONE YEAR PARTS AND 30 DAY LABOR WARRANTY:

All components excluding normal wear items as described below.

WARRANTY PROVIDED BY OTHER MANUFACTURERS:

Motors, which are warranted by their respective manufacturers, are serviced through these manufacturers' local authorized service centers. *WATER MAZE* cannot provide warranty on these items.

WHAT THIS WARRANTY DOES NOT COVER

This warranty does not cover the following items:

1. Normal wear items, such as seals, filters, gaskets, O-rings, packings, pistons, brushes, filtering media, ozone bulbs, sensors, UV scanners, oil-skimmer belt, impedance sensor. Minor leaks covered first time on original start-up only.
2. Damage or malfunctions resulting from accidents, abuse, modifications, alterations, incorrect installation, improper servicing, failure to follow manufacturer's maintenance instructions, or use of the equipment beyond its stated usage specifications as contained in the operator's manual.
3. Damage due to freezing, sludge build-up, chemical deterioration (oxidation, chloride or fluoride corrosion), and rust.
4. Damage to components from fluctuations in electrical or water supply.
5. Normal maintenance service, including adjustments.
6. Transportation to service center, field labor charges, or freight damage.
7. Consumables and water quality.

WHAT YOU MUST DO TO OBTAIN WARRANTY SERVICE

While not required for warranty service, we request that you register your *WATER MAZE* Product by returning the completed registration card. In order to obtain warranty service on items warranted by *WATER MAZE*, you must return the product to your Authorized *WATER MAZE* Dealer, freight prepaid, with proof of purchase, within the applicable warranty period. If the product is permanently installed, you must notify your Authorized *WATER MAZE* Dealer of the defect. Your Authorized *WATER MAZE* Dealer will file a claim with *WATER MAZE*, who must subsequently verify the defect. In most cases, the part must be returned to *WATER MAZE* freight prepaid with the claim. For warranty service on components warranted by other manufacturer's, your Authorized *WATER MAZE* Dealer can help you obtain warranty service through these manufacturers' local authorized service centers.

LIMITATION OF LIABILITY

WATER MAZE'S liability for special, incidental, or consequential damages is expressly disclaimed. In no event shall *WATER MAZE'S* liability exceed the purchase price of the product in question. *WATER MAZE* makes every effort to ensure that all illustrations and specifications are correct, however, these do not imply a warranty that the product is merchantable or fit for a particular purpose, or that the product will actually conform to the illustrations and specifications. Our obligation under this warranty is expressly limited at our option to the replacement or repair at a service facility or factory designated by us, of such part or parts as inspection shall disclose to have been defective. **THE WARRANTY CONTAINED HEREIN IS IN LIEU OF ALL OTHER WARRANTIES, EXPRESS OR IMPLIED, INCLUDING ANY IMPLIED WARRANTY WATER QUALITY, MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE ARE EXPRESSLY LIMITED TO THE DURATION OF THIS WARRANTY.** This warranty gives you specific legal rights and you may also have other rights which vary from state to state. *WATER MAZE* does not authorize any other party, including authorized *WATER MAZE* Distributors, to make any representation or promise on behalf of *WATER MAZE*, or to modify the terms, conditions, or limitations in any way. It is the buyer's responsibility to ensure that the installation and use of *WATER MAZE* products conforms to local codes. While *WATER MAZE* attempts to assure that its products meet national codes, it cannot be responsible for how the customer chooses to use or install the product. Some states do not allow limitations or exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to you.



ALPHA • #8.913-964.0-B • Revised 5/15 • Printed in U.S.A.