

Floor care for matt stone/linoleum/PVC RM 532

Optimum care and protection for matt artificial and natural stone floors, linoleum and PVC. Traces are removed, the care film is renewed and the floor is left with a silky matt shine. Notes: Allow treated floors to harden for 24 hours, do not apply water, do not move furniture and do not walk on the floor wearing shoes. Store in a frost-free place.



Properties

- Optimal care and protection
- Freshening
- Gives a semi-matt shine
- Polishes well
- Tailored to Kärcher devices with guaranteed material compatibility
- The body of the bottle is made from 100% recycled plastic
- Made in Germany

Application areas

Matte natural and synthetic stone floors
Linoleum floors
PVC floors

Usage options

- Manual
- Vacuum polishers

Technical data

Container sizes	Packaging unit	Part number
1 l	6 Piece(s)	6.295-776.0

Application

For first application

- Vacuum and damp wipe floor.
- Wash the mop out and wring until damp.
- Use 10 ml/m² of care agent and distribute uniformly in sections with the wiping mop.
- Allow damp care film to dry fully (approx. 20-30 mins) and then polish the floor.

Application on protected floors

- Vacuum the floor.
- Add 30 ml/l to the wiping water, wipe floor to make it slightly damp, allow to dry and polish if necessary.

Instructions for use

- Let treated floors dry for 24 hours.
- Do not use water.
- Do not move furniture or walk on in shoes.
- Store away from frost.