


# KÄRCHER

makes a difference

## Quicker to use than a vacuum cleaner

We all know the problem: as soon as you have finished vacuuming, there are crumbs on the floor again already. The cordless electric broom from Kärcher is ideal for intermediate cleaning - without having to get the vacuum cleaner out again. Thanks to its compact and modern design, the cordless electric broom can be stored wherever it is needed and is always ready to use. For a visibly clean home without the effort.



## Always ready to use

The battery-powered KB 5 does not need to be plugged into a power outlet and is therefore always ready to use. Lithium-ion battery technology enables a battery running time of up to 30 minutes on hard surfaces.



## Extraordinary cleaning performance in a compact design

The innovative Kärcher Adaptive Cleaning System of the Kärcher cordless electric broom provides brilliant cleaning results. Thanks to the movable sweeping edge, optimal dirt guidance and special cleaning brush, the dirt is transported efficiently into the rubbish bin without residue and dust dispersion.

Please contact us for more information:

### Head Office Germany

Alfred Kärcher GmbH & Co. KG  
Alfred-Kärcher-Straße 28-40  
71364 Winnenden

Phone +49 71 95-14-0  
Fax +49 71 95-14-2212

[www.kaercher.com](http://www.kaercher.com)

### North America

Kärcher North America  
4555 Airport Way  
Denver, CO 80239  
USA

Phone +1 303-738-5805  
Fax +1 303-738-2758

[www.karcherna.com](http://www.karcherna.com)

### United Kingdom

Kärcher (UK) Ltd  
Kärcher House  
Brookhill Way  
Banbury  
Oxon OX16 3ED

Phone +44 1295-752-000  
Fax +44 1295-752-103

[www.karcher.co.uk](http://www.karcher.co.uk)

### Ireland

Kärcher Ltd  
Unit 4  
E.P. Mooney Business Park  
Walkinstown Avenue  
Dublin 12

Phone +353 1-409-7777  
Fax +353 1-409-7775

[www.karcher.ie](http://www.karcher.ie)

### South East Asia

Regional Head Office  
South East Asia

Kärcher Services  
Asia Pacific Pte Ltd  
3 Depot Close #05-01  
Singapore 109840

Phone +65 6897-1811  
Fax +65 6897-1611

[www.karcher.com.sg](http://www.karcher.com.sg)

### Hong Kong

Kärcher Limited  
Unit 05, 13/F, Nanyang Plaza  
57 Hung To Road  
Kwun Tong, Kowloon

Phone +852 2-357-5863  
Fax +852 2-357-5632

[www.karcher.com.hk](http://www.karcher.com.hk)

### Australia

Kärcher Pty Ltd  
40 Koornang Road  
Scoresby VIC 3179  
Melbourne, Victoria

Phone +61 3-9765-2300  
Fax +61 3-9765-2398

[www.karcher.com.au](http://www.karcher.com.au)

### New Zealand

Kärcher Ltd  
66 Allens Road  
East Tamaki  
Auckland 2013

Phone +64 9-274-4603  
Fax +64 9-274-6932

[www.karcher.co.nz](http://www.karcher.co.nz)

### South Africa

Kärcher (Pty) Ltd  
Cnr Mount Joy  
& George Allen Rd  
Wilbart Ext. 2  
PO Box 11818  
Vorna Valley, 1686

Phone +27 11-657-7300  
Fax +27 11-657-7440

[www.karcher.co.za](http://www.karcher.co.za)

### Dubai

Kärcher FZE  
Quality Cleaning Systems  
Jebel Ali Free Zone  
Plot No. S-10104 South Zone  
RA 08, XB 1, Jebel Ali

Phone +971 4-886-1177  
Fax +971 4-886-1575

[www.kaercher.com](http://www.kaercher.com)

RN/TST - 11/2016 - Order no. 0.032-314.0 - Printed in Germany on chlorine-free bleached paper - Rights to technical modifications reserved.



## ACCIDENTS HAPPEN. CLEAN THEM UP AS EASY AS CHILD'S PLAY.

Be prepared for anything with the new  
Kärcher KB 5 Cordless Electric Broom.



HOME & GARDEN | CORDLESS ELECTRIC BROOM

# IDEAL FOR QUICK CLEANING.

The KB 5 cordless electric broom is small, manoeuvrable and immediately ready to use – ideal for all around the home. Perfect for quick and effective intermediate cleaning.



**Reliable dirt removal**  
Efficiently removes dirt on all carpets and hard surfaces. In next to no time.



**Corner and edge cleaning**  
The cordless electric broom effortlessly removes dirt from corners and edges.




**Manoeuvrability**  
The flexible double joint makes the cordless electric broom very manoeuvrable – even easy to manoeuvre on stairs.



**Automatic on/off function**  
Thanks to intuitive operation, the cordless electric broom can be switched on and off quickly and easily.



**Rubbish bin**  
The laterally removable container enables quick and easy emptying without contact with dirt.



**Cleans under furniture**  
Floor cleaning is easy – even under furniture.



“I have just finished vacuuming and there are crumbs on the floor again already. All I need to do is use the cordless electric broom – and everything is clean again.”



## KB 5

- Space-saving storage due to compact design
- Designed for optimal dirt pick-up and removal
- Suitable for all standard floor coverings

### Technical data

Max. battery running time	min	30
Working width	mm	210
Container capacity	ml	370
Battery voltage	V	3.7
Battery technology		Lithium-ion battery (Li-ion)
Weight	kg	1.2
Dimensions with handle (L × W × H)	mm	220 × 233 × 1120

### Equipment

Universal brush	removable
Battery charger	■
Order number	1.258-000.0

- Included in scope of supply.

