



Multi-Surface Cleaner Concentrate RM 508

The Multi-Surface Cleaner Concentrate RM 508 can be used throughout the household, quick and streak-free drying and is suitable for all water-resistant surfaces.



Properties

- Universal surface cleaning concentrate
- Effectively removes food spills, grease stains, nicotine deposits, coffee stains, shoe polish, footprints, etc.
- Very good cleaning power on all water-resistant and alcohol-resistant hard and flexible surfaces
- Streak-free even on high-gloss surfaces
- Pleasant, fresh citrus scent
- Tailored to Kärcher devices with guaranteed material compatibility
- The body of the bottle is made from 100% recycled plastic
- Made in Germany

Application areas

Surface cleaning

Usage options

- Vibrating battery wiper
- Manual

Technical data

Container sizes	Packaging unit	Part number
500 ml	8 Piece(s)	6.296-128.0

Application

Window Vacs

- Add 1.5 caps (30 ml) of concentrate to the spray bottle and fill with 220 ml of water.

Vibrating battery wiper KV 4

- Fill the tank of the KV 4 with tap water to just below the MAX line. Add a cap (20ml) of Multi-Surface Cleaner Concentrate. Turn KV 4 once to mix.

Manual

- Mix 50-100ml of Multi-Surface Cleaner (3-5 caps) with 1L of water. Use as normal with cloth or mop.

Warnings and safety recommendations according to EC Directives

- P102 Keep out of reach of children.