




K2 Compact Home

Compact and lightweight, the Kärcher K2 Compact Home is ideal for cleaning tasks around the home and includes a Home kit with a T150 patio cleaner and detergent.



1 Compact And Tidy Storage

- Not all living spaces come with generous storage space. The Kärcher K 2 Basic pressure washer's upright design saves you space, while the on-board storage solutions keep your Kärcher accessories, cables, hose and trigger gun stored neatly on the machine.



2 Full cleaning power

- While the Kärcher K 2 Home jet washer may be small enough to store in a cupboard or in the boot of your car, it still has a powerful cleaning capacity expected from all our models.



3 Sits Comfortably In The Hand

- Thanks to the ergonomic carrying handle and the low weight, the device is light and easy to transport, making pressure washing portable and convenient around the home.



K2 Compact Home

- Sits comfortably in the hand: ergonomic carrying handle
- Spray lance storage

Technical data

Order no.	1.673-127.0	
EAN code	4039784824492	
Current type	V / Hz	220 - 240 / 50 - 60
Pressure	bar / MPa	110 / 11
Flow Rate	l/h	max. 360
Water feed temperature	°C	max. 40
Area performance	m²/h	20
Power rating	kW	1,4
Weight without accessories	kg	4,08
Dimensions (L x W x H)	mm	176 x 280 x 443

Equipment

High-pressure gun	Standard Quick Connect	
Vario Power spray lance	-	
One-way spray lance	■	
Dirt Blaster spray lance	■	
High-pressure hose	m	4
Quick Connect on machine	■	
Detergent application via	Suction	
Integrated water filter	■	
Adapter garden hose A3/4"	■	

Home kit T150 Patio Cleaner, 0,5 L Patio & Deck Detergent

■ Included in delivery.

K2 COMPACT HOME

1.673-127.0

KÄRCHER


		Order no.						Price	Description	
Hard surface cleaners										
T 5 T-Racer Surface Cleaner	1	2.644-084.0							Thorough and splash-free cleaning over large areas: The T 5 T-Racer surface cleaner is ideal for cleaning hard and soft surfaces alike.	☐
PS 30 power scrubber surface cleaner	2	2.644-123.0							The PS 30 power scrubber, with its three integrated high-pressure nozzles, powerfully removes stubborn dirt from various surfaces, while saving time. Ideal for stairs and edges. Includes integrated squeegee blade to remove the dirty water.	☐
PS 30 Plus	3	2.644-212.0								☐
PS 40 Power Scrubber	4	2.643-245.0							The Kärcher PS40 power scrubber comes with three integrated high-pressure nozzles giving you a powerful, reliable and time-saving solution for removing stubborn dirt on a variety of surfaces.	☐
T350 Patio Cleaner	5	2.643-252.0							The Kärcher T350 patio cleaner allows you to clean large areas quickly and efficiently, as well as being splash-free. This model includes adjustable cleaning pressure for different surfaces.	☐
Brushes										
WB 150 power brush	6	2.643-237.0							The Kärcher WB150 pressure washer brush is the perfect attachment for cleaning delicate surfaces such as car exteriors, motorbikes, glass, garage doors and conservatories.	☐
WB 120	7	2.644-060.0								☐
WB 130 rotating wash brush	8	2.644-286.0								☐
WB 120 Car & Bike	9	2.644-129.0								☐
WB 130 rotating wash brush car & bike	10	2.644-287.0								☐
WB60 Soft Surface Wash Brush	11	2.643-233.0							The Kärcher WB60 soft wash brush is a great addition to your Kärcher pressure washer to help you clean larger surfaces like cars, caravans, boats and conservatories.	☐
Wheel Washing Brush	12	2.643-234.0							The Kärcher wheel washing brush is perfect for removing dirt and grime that accumulates on your wheel rims. With 360° degree cleaning enabling you to reach every angle of your wheels.	☐
Washing brush rigid	13	6.903-276.0							Standard Kärcher brush for pressure washers. Perfect for removing stubborn dirt and cleaning a wide variety of firm surfaces, from cars and caravans to windows and garden furniture.	☐
Adapter for garden hose connection	14	2.640-732.0								☐
WB100 Rotating Wash Brush	15	2.643-236.0							The Kärcher WB100 rotating wash brush is ideal for cleaning all smooth surfaces like paint, glass or plastic. It comes with a 180° joint making it infinitely adjustable.	☐
Spray lances										
Telescopic jet pipe with joint	16	2.644-190.0								☐
TLA 4 + Facade cleaner (Bundle)	17	2.644-249.0								☐
Splash guard	18	2.642-706.0								☐
Angled spray lance	19	2.638-817.0							Extra-long angled spray lance (about 1 m) for easy cleaning of difficult to reach areas, e.g. roof gutters or vehicle underbodies.	☐

☐ Available accessories.

K2 COMPACT HOME 1.673-127.0

KÄRCHER


		Order no.						Price	Description	
Single Lance Extension	20	2.643-240.0							Extends spray lance by 0.5 m. For effective cleaning of difficult to reach areas. Suitable for all Kärcher accessories.	☐
Mini VP160 Vario Power Jet	21	2.643-254.0							The Kärcher Mini Vario Power Jet comes with infinite pressure regulation and an adjustable 360° joint, ideal for cleaning difficult to reach areas. For use with K2 - K7 pressure washers.	☐
Telescopic jet pipe	22	2.642-347.0							The Kärcher Telescopic jet pipe allows for easy cleaning of difficult to reach areas. With a shoulder strap and an ergonomically adjustable trigger gun, allowing you to reach up to 4m.	☐
Dirt Blaster Pressure Washer Lance	23	2.643-244.0							A powerful rotating nozzle ideal for removing stubborn dirt such as moss, algae and ground-in dirt, the Kärcher Dirt Blaster is the perfect attachment for tough cleaning jobs.	☐
Trigger guns										
G 160 Q	24	2.642-889.0								☐
High Pressure Replacement Hose with Anti-Twist system and Quick Connect system										
H 10 Q PremiumFlex Anti-Twist	25	2.643-585.0							The new Kärcher anti-twist high-pressure hose makes working with your pressure washer that much easier. Thanks to the anti-twist system knots in the high-pressure hose untie themselves.	☐
High-pressure hose extension - System from 2009										
High-pressure replacement hose, 9 m, K3 - K7	26	2.641-721.0							9 m high-pressure replacement hose for K3 - K7 series domestic pressure washers from 2009, where the hose is connected to the gun and pressure washer per Quick Connect connector, 160 bar, 60 °C.	☐
High-pressure hose replacement kit - from 1992										
Adapter Set Extension Hose	27	2.643-037.0								☐
High-pressure hose extension - System from 2008										
XH 6 Q Extension Hose Quick Connect	28	2.641-709.0							High-pressure extension hose for greater flexibility. 6 m robust DN 8 quality hose for durability. For K 2 - K 7 series from 2008 with Quick Connect connector. Connect between spray gun and high-pressure hose.	☐
Pipe Cleaning										
Roof gutter and pipe cleaning set	29	2.642-240.0							The Kärcher roof gutter and pipe cleaning kit is an effective way to clean and remove blockages in pipes, drains, downpipes and toilets. Compatible with all Kärcher pressure washers.	☐
Pipe cleaning set, 15 m	30	2.637-767.0							Pipe cleaning set with 15 m hose for clearing blockages in pipes, drains, downpipes and toilets.	☐
Pipe cleaning set, 7.5 m	31	2.637-729.0							Pipe cleaning set with 7.5 m hose for clearing blockages in pipes, drains, downpipes and toilets.	☐
Foam jet										
FJ 6 foam nozzle	32	2.643-147.0							The Kärcher FJ6 foam nozzle is the perfect addition to your Kärcher pressure washer, allowing you to add a layer of foamy detergent with the minimum of effort and fuss.	☐
Foam nozzle Connect 'n' Clean FJ10 C Ultra Foam Cleaner 1L	33	2.643-143.0							The Kärcher Ultra Foam Detergent & FJ10 C Connect 'n' Clean foam nozzle is the most effective way to apply detergent. Allowing you to switch between detergents for different tasks.	☐
FJ 10 C Connect 'n' Clean Foam and Care nozzle with Car Shampoo	34	2.643-144.0							Car Shampoo & FJ 10 C Connect 'n' Clean foam nozzle - The most effective way to apply detergent. Also allows a simple switch between different detergents for different tasks.	☐

☐ Available accessories.

K2 COMPACT HOME

1.673-127.0

KÄRCHER



		Order no.						Price	Description	
Accessory kits										
Bike Cleaning accessory kit	35	2.643-551.0							The bike cleaning accessory kit from Kärcher is the perfect addition to your pressure washer to help you clean your motor bike. This kit help you achieve the perfect clean for your bike.	☐
Wood Cleaning Accessory Kit	36	2.643-553.0							Kärcher's wood cleaning accessory kit is perfect for cleaning all wooden surfaces. From garden furniture to decking, this accessory kit will help you achieve the perfect clean.	☐
Miscellaneous										
Sand/wet blasting set	37	2.638-792.0							Sand and wet blasting set for removing rust, paint and stubborn dirt using Kärcher abrasive.	☐
Vario joint	38	2.640-733.0							Vario joint, rotates 180° for cleaning difficult to reach areas. Connection: For connection between gun and accessory or extension lance and accessory.	☐
Water filter	39	4.730-059.0							Water filter protects pressure washer pumps against dirt particles from dirty water.	☐
Replacement O-ring set	40	2.640-729.0								☐
Kärcher organiser	41	2.641-630.0							Kärcher organiser, the practical wall-mounted storage system for Kärcher accessories. With two modules for flexible mounting. Ideal for protecting wash brushes and bristles from bending.	☐

☐ Available accessories.

K2 COMPACT HOME

1.673-127.0

KÄRCHER



		Order no.						Price	Description	
Hose Storage and Hose Trolley										
Premium Hose Reel HR 7.315 Kit 5/8"	1	2.645-165.0							Watering Station for the practical and space-saving storage of hoses and garden accessories. With removable drum, storage for nozzles, spray guns, and spray lances and spacious storage box.	☐
Premium Hose Reel HR 7.315 Kit 1/2"	2	2.645-164.0							Watering Station for the practical and space-saving storage of hoses and garden accessories. With removable drum, storage for nozzles, spray guns, and spray lances and spacious storage box.	☐
Hoses										
Connection Set for high-pressure cleaners	3	2.645-156.0							Hose set for high pressure cleaning or for watering the garden. With 10 m PrimoFlex®-hose (3/4"), G3/4-tap adapter, 1 x Universal hose connector as well as Universal hose connector with Aqua Stop.	☐
Indoor Hose Connection Set	4	2.645-258.0							This indoor hose connection set provides the perfect solution if you need to connect your power washer to an indoor tap.	☐
PrimoFlex® Hose: 1/2" - 20m	5	2.645-138.0							This PrimoFlex® hose is durable, with a woven reinforced garden hose with pressure resistant features and operating temperature range from -20 to 65°C, making it ideal for gardening.	☐
PrimoFlex® hose 3/4" - 25 m	6	2.645-142.0							PrimoFlex® quality garden hose (3/4") 25 m. Pressure-resistant, reinforced braided. Unharmful to health. Bursting pressure: 24 bar. Wide operating temperature range from -20 to 65 °C.	☐
Hose Performance Plus 1/2" - 20m	7	2.645-318.0							Robust and extremely resistant to kinks, the Performance Plus garden hose is made from high-quality multi-layered woven material - for proven quality and performance.	☐
Hose Performance Plus 3/4" -25m	8	2.645-322.0								☐
Performance Premium hose, 1/2" - 20 m	9	2.645-324.0							The ultra-flexible and kink-resistant Performance Premium garden hose. Designed with Kärcher's Premium anti-torsion technology, for better performance and durability.	☐
Connectors/Tap adaptors										
Universal hose coupling Plus	10	2.645-193.0							Universal hose coupling plus with soft plastic recessed grips for comfortable handling. Compatible with all click systems.	☐
Universal hose coupling Plus with Aqua Stop	11	2.645-194.0							Universal hose coupling plus with Aqua Stop and soft plastic recessed grips for comfortable handling. Compatible with all click systems.	☐
Universal hose coupling with Aqua Stop	12	2.645-192.0							Universal hose coupling with Aqua Stop. Ergonomic design for convenient handling.	☐
Universal hose coupling	13	2.645-191.0							Our universal hose coupling is an essential part of the Kärcher garden irrigation system, extending the length of your hose to make sure every inch of your garden gets the care it deserves.	☐

☐ Available accessories.