





## K 2 Full Control Home

The K 2 Full Control Home power washer includes the new targeted pressure regulation trigger gun. This machine includes a home kit with a patio cleaner accessory and detergent.

MISSING  
PIC-  
TURE: D:\  
IM0027641



### 1 Full Control Click Vario Power spray lance and Dirt Blaster

- Gives you direct feedback as to the pressure setting you are on, ensuring you get the right pressure setting for the surface you are trying to clean.
- Settings are chosen by turning the Full Control Click Vario Power spray lance

### 2 Supports for accessories, high-pressure gun and cable

- Spray lances are always within easy reach and everything can be compactly stored on the device once cleaning is complete.
- Not all living spaces come with generous storage space. The Kärcher K2 home pressure washer's upright design saves you space, while the on-board storage solutions keep your Kärcher accessories, cables plus hose and trigger gun stored neatly on the machine.

### 3 Detergent use

- Suction hose for use of detergents.
- Kärcher detergents increase efficiency while cleaning, help prevent dirt from returning and help to protect and care for your surface.

### 4 Telescopic handle

- For a convenient pulling height.
- Completely retractable for a compact storage solution.



## K 2 Full Control Home

- Full Control Click Vario Power spray lance with pressure setting display
- Extendable telescopic handle
- Spray lance storage

### Technical data

<b>Order Number</b>	1.673-405.0	
<b>EAN code</b>	4054278246598	
<b>Pressure</b>	bar / MPa	20-110 / 2-11
<b>Flow rate</b>	l/h	360
<b>Max. water feed temperature</b>	°C	max. 40
<b>Power rating</b>	kW	1,4
<b>Weight without accessories</b>	kg	4,3
<b>Dimensions (L x W x H)</b>	mm	246 x 280 x 586
<b>Current type</b>	V	220-240
<b>Area performance</b>	m <sup>2</sup> /h	20

### Equipment

<b>High-pressure gun</b>	G 120 Q	
<b>Vario Power spray lance</b>	-	
<b>Dirt Blaster spray lance</b>	■	
<b>High-pressure hose</b>	m	4
<b>Quick Connect on machine</b>	■	
<b>Detergent application via</b>	Suction	
<b>Integrated water filter</b>	■	
<b>Adapter garden hose A3/4"</b>	■	
<b>Home kit</b>	T150 Patio Cleaner, 0.5 L Patio & Deck Detergent	
<b>Click VPS</b>	■	

■ Included in delivery.

# K 2 FULL CONTROL HOME 1.673-405.0

**KÄRCHER**



		Order Number					Price	Description	
<b>Spray lances</b>									
Full Control Vario Power Jet for K2 - K3, VP120	1	2.642-724.0						Vario Power spray lance for pressure washers in the K2-K3 range. With continuously adjustable pressure by simply by turning the spray lance, you will have a setting for every task.	■
Full Control Dirt Blaster for K2 - K3, DB120	2	2.642-727.0						Dirt Blaster spray lance for K2 and K3 Kärcher pressure washers. This lance is perfect for tackling tough, stuck-on dirt like that on mossy or weathered surfaces.	■
Telescopic jet pipe	3	2.642-347.0						The Kärcher Telescopic jet pipe allows for easy cleaning of difficult to reach areas. With a shoulder strap and an ergonomically adjustable trigger gun, allowing you to reach up to 4m.	□
Splash guard	4	2.642-706.0						The transparent splash guard for K2 to K7 Kärcher pressure washers protects you and the surrounding area from spray water. Ideal for cleaning corners and edges.	□
Angled spray lance	5	2.638-817.0						Extra-long angled spray lance (about 1 m) for easy cleaning of difficult to reach areas, e.g. roof gutters or vehicle underbodies.	□
Single Lance Extension	6	2.643-240.0						Extends spray lance by 0.5 m. For effective cleaning of difficult to reach areas. Suitable for all Kärcher accessories.	□
Mini VP160 Vario Power Jet	7	2.643-254.0						The Kärcher Mini Vario Power Jet comes with infinite pressure regulation and an adjustable 360° joint, ideal for cleaning difficult to reach areas. For use with K2 - K7 pressure washers.	□
<b>Hard surface cleaners</b>									
PS 40 Power Scrubber	8	2.643-245.0						The Kärcher PS40 power scrubber comes with three integrated high-pressure nozzles giving you a powerful, reliable and time-saving solution for removing stubborn dirt on a variety of surfaces.	□
T350 Patio Cleaner	9	2.643-252.0						The Kärcher T350 patio cleaner allows you to clean large areas quickly and efficiently, as well as being splash-free. This model includes adjustable cleaning pressure for different surfaces.	□
Spare nozzles accessories	10	2.643-338.0						High-quality replacement nozzles for all T-Racer surface cleaners (except T 350) for unit classes K 2 to K 7, gutter cleaner PC 20 for K 3 to K 7, as well as chassis cleaner for K 2 to K 5.	□
Spare nozzles accessories T 300 / T 350	11	2.643-335.0							□
<b>Special applications</b>									
FJ 6 foam nozzle	12	2.643-147.0						The Kärcher FJ6 foam nozzle is the perfect addition to your Kärcher pressure washer, allowing you to add a layer of foamy detergent with the minimum of effort and fuss.	□
Foam nozzle Connect 'n' Clean FJ10 C Ultra Foam Cleaner 1L	13	2.643-143.0						The Kärcher Ultra Foam Detergent & FJ10 C Connect 'n' Clean foam nozzle is the most effective way to apply detergent. Allowing you to switch between detergents for different tasks.	□
FJ 10 C Connect 'n' Clean Foam and Care nozzle with Car Shampoo	14	2.643-144.0						Car Shampoo & FJ 10 C Connect 'n' Clean foam nozzle - The most effective way to apply detergent. Also allows a simple switch between different detergents for different tasks.	□
Roof gutter and pipe cleaning set	15	2.642-240.0						The Kärcher roof gutter and pipe cleaning kit is an effective way to clean and remove blockages in pipes, drains, downpipes and toilets. Compatible with all Kärcher pressure washers.	□

■ Included in delivery. □ Available accessories.

# K 2 FULL CONTROL HOME

## 1.673-405.0

**KÄRCHER**



		<b>Order Number</b>					<b>Price</b>	<b>Description</b>	
Pipe cleaning set, 15 m	16	2.637-767.0						Pipe cleaning set with 15 m hose for clearing blockages in pipes, drains, downpipes and toilets.	<input type="checkbox"/>
Pipe cleaning set, 7.5 m	17	2.637-729.0						Pipe cleaning set with 7.5 m hose for clearing blockages in pipes, drains, downpipes and toilets.	<input type="checkbox"/>
Vario joint	18	2.640-733.0						Vario joint, rotates 180° for cleaning difficult to reach areas. Connection: For connection between gun and accessory or extension lance and accessory.	<input type="checkbox"/>
Kärcher organiser	19	2.641-630.0						Kärcher organiser, the practical wall-mounted storage system for Kärcher accessories. With two modules for flexible mounting. Ideal for protecting wash brushes and bristles from bending.	<input type="checkbox"/>
FJ 10 C Connect 'n' Clean Foam and Care nozzle with Stone Cleaner	20	2.643-145.0						3in1 Stone cleaner & FJ 10 C Connect 'n' Clean foam nozzle - The most effective way to apply detergent. Also allows a simple switch between different detergents for different tasks.	<input type="checkbox"/>
Sand/wet blasting set	21	2.638-792.0						Sand and wet blasting set for removing rust, paint and stubborn dirt using Kärcher abrasive.	<input type="checkbox"/>
<b>Brushes</b>									
WB 150 power brush	22	2.643-237.0						The Kärcher WB150 pressure washer brush is the perfect attachment for cleaning delicate surfaces such as car exteriors, motorbikes, glass, garage doors and conservatories.	<input type="checkbox"/>
WB60 Soft Surface Wash Brush	23	2.643-233.0						The Kärcher WB60 soft wash brush is a great addition to your Kärcher pressure washer to help you clean larger surfaces like cars, caravans, boats and conservatories.	<input type="checkbox"/>
Wheel Washing Brush	24	2.643-234.0						The Kärcher wheel washing brush is perfect for removing dirt and grime that accumulates on your wheel rims. With 360° degree cleaning enabling you to reach every angle of your wheels.	<input type="checkbox"/>
Adapter for garden hose connection	25	2.640-732.0							<input type="checkbox"/>
WB100 Rotating Wash Brush	26	2.643-236.0						The Kärcher WB100 rotating wash brush is ideal for cleaning all smooth surfaces like paint, glass or plastic. It comes with a 180° joint making it infinitely adjustable.	<input type="checkbox"/>
WB 120	27	2.644-060.0							<input type="checkbox"/>
WB 120 Car & Bike	28	2.644-129.0							<input type="checkbox"/>
Washing brush rigid	29	6.903-276.0						Standard Kärcher brush for pressure washers. Perfect for removing stubborn dirt and cleaning a wide variety of firm surfaces, from cars and caravans to windows and garden furniture.	<input type="checkbox"/>
<b>High Pressure Replacement Hose with Anti-Twist system and Quick Connect system</b>									
H 10 Q PremiumFlex Anti-Twist	30	2.643-585.0						The new Kärcher anti-twist high-pressure hose makes working with your pressure washer that much easier. Thanks to the anti-twist system knots in the high-pressure hose untie themselves.	<input type="checkbox"/>
<b>High-pressure hose extension - System from 2009</b>									
High-pressure replacement hose, 9 m, K3 - K7	31	2.641-721.0						9 m high-pressure replacement hose for K3 - K7 series domestic pressure washers from 2009, where the hose is connected to the gun and pressure washer per Quick Connect connector, 160 bar, 60 °C.	<input type="checkbox"/>
<b>High-pressure hose replacement kit - from 1992</b>									
Adapter Set Extension Hose	32	2.643-037.0							<input type="checkbox"/>

■ Included in delivery. □ Available accessories.

# K 2 FULL CONTROL HOME 1.673-405.0



		Order Number					Price	Description	
<b>High-pressure hose extension - System from 2008</b>									
High-pressure extension hose, 6 m, K3 - K7 (for gun model "Best").	33	2.641-709.0						High-pressure extension hose for greater flexibility. 6 m robust DN 8 quality hose for durability. For K3 - K7 series from 2008 with Quick Connect connector.	<input type="checkbox"/>
<b>Miscellaneous</b>									
G 160 Q	34	2.642-889.0							<input type="checkbox"/>
Water filter	35	4.730-059.0						Water filter protects pressure washer pumps against dirt particles from dirty water.	<input type="checkbox"/>
Replacement O-ring set	36	2.640-729.0							<input type="checkbox"/>
<b>Accessory kits</b>									
Bike Cleaning accessory kit	37	2.643-551.0						The bike cleaning accessory kit from Kärcher is the perfect addition to your pressure washer to help you clean your motor bike. This kit help you achieve the perfect clean for your bike.	<input type="checkbox"/>
Wood Cleaning Accessory Kit	38	2.643-553.0						Kärcher's wood cleaning accessory kit is perfect for cleaning all wooden surfaces. From garden furniture to decking, this accessory kit will help you achieve the perfect clean.	<input type="checkbox"/>

■ Included in delivery. □ Available accessories.

# K 2 FULL CONTROL HOME 1.673-405.0

**KÄRCHER**



		Order Number					Price	Description	
<b>Connectors/Tap adaptors</b>									
Universal hose coupling Plus	1	2.645-193.0						Universal hose coupling plus with soft plastic recessed grips for comfortable handling. Compatible with all click systems.	<input type="checkbox"/>
Universal hose coupling Plus with Aqua Stop	2	2.645-194.0						Universal hose coupling plus with Aqua Stop and soft plastic recessed grips for comfortable handling. Compatible with all click systems.	<input type="checkbox"/>
Universal hose coupling with Aqua Stop	3	2.645-192.0						Universal hose coupling with Aqua Stop. Ergonomic design for convenient handling.	<input type="checkbox"/>
Universal hose coupling	4	2.645-191.0						Our universal hose coupling is an essential part of the Kärcher garden irrigation system, extending the length of your hose to make sure every inch of your garden gets the care it deserves.	<input type="checkbox"/>
<b>Hoses</b>									
Connection Set for high-pressure cleaners	5	2.645-156.0						Hose set for high pressure cleaning or for watering the garden. With 10 m PrimoFlex®-hose (3/4"), G3/4-tap adapter, 1 x Universal hose connector as well as Universal hose connector with Aqua Stop.	<input type="checkbox"/>
Indoor Hose Connection Set	6	2.645-258.0						This indoor hose connection set provides the perfect solution if you need to connect your power washer to an indoor tap.	<input type="checkbox"/>
PrimoFlex® Hose: 1/2" - 20m	7	2.645-138.0						This PrimoFlex® hose is durable, with a woven reinforced garden hose with pressure resistant features and operating temperature range from -20 to 65°C, making it ideal for gardening.	<input type="checkbox"/>
PrimoFlex® hose 3/4" - 25 m	8	2.645-142.0						PrimoFlex® quality garden hose (3/4") 25 m. Pressure-resistant, reinforced braided. Unharmful to health. Bursting pressure: 24 bar. Wide operating temperature range from -20 to 65 °C.	<input type="checkbox"/>
<b>Hose Storage and Hose Trolley</b>									
Premium Hose Reel HR 7.315 Kit 5/8"	9	2.645-165.0						Watering Station for the practical and space-saving storage of hoses and garden accessories. With removable drum, storage for nozzles, spray guns, and spray lances and spacious storage box.	<input type="checkbox"/>
Premium Hose Reel HR 7.315 Kit 1/2"	10	2.645-164.0						Watering Station for the practical and space-saving stowage of hoses and garden accessories. With removable drum, storage for nozzles, spray guns, and spray lances and spacious storage box.	<input type="checkbox"/>

■ Included in delivery. □ Available accessories.