



S 4

From petals in spring to leaves in autumn and grit in winter, the Kärcher S 4 sweeper makes light work of all your sweeping tasks. It collects the sweepings in its 20-litre waste hopper.




1 Practical cap for side brush

- Tool-free side brush attachment for rapid set-up and deployment.



2 Comfortable Footplate

- Collapse sweeper fully without stooping - for space-saving storage.



3 Infinitely variable push handle

- Back-friendly sweeping thanks to individual height adjustment.



4 Large Waste Hopper

- Frequent emptying of waste hopper is not necessary.



S 4

- Ideal for smaller outdoor areas
- One side brush

Technical data

Order no.	1.766-320.0	
EAN code	4054278247922	
Working Width With Side Brush	mm	510
Max. Area Performance	m ² /h	1800
Housing/Frame	Plastic/Plastic	
Weight, ready to operate	kg	9,8
Waste Container	l	20

Equipment

Number of side brushes	Piece(s)	1
Ergonomic Push Handle		■
Stepless Adjustable Push Handle		■
Storage Position		■
Tread surface for space-saving storage		■
Tool-Free Side Brush Attachment		■
Stand-alone waste container		■

■ Included in delivery.

S 4

1.766-320.0



		Order no.					Price	Description	
Sweepers									
S4 side brushes for wet waste	1	2.644-032.0						These sweeper side brushes make light work of your sweeping tasks, from petals in spring to autumn leaves, winter grit and wet waste. Suitable for the S 4 Twin sweepers.	<input type="checkbox"/>

Available accessories.