

UNIVERSAL BRUSH

The universal brush is mounted onto the trigger gun of the portable cleaner, to help you remove stubborn dirt while protecting delicate components.



Order no. 2.643-870.0

| Technical data | | |
|------------------------|----|---------------|
| EAN code | | 4054278243238 |
| Weight | kg | 0.1 |
| Weight incl. packaging | kg | 0.1 |
| Dimensions (L × W × H) | mm | 200 × 80 × 80 |

KARCHER



Can be attached to the trigger gun

• One hand is therefore kept free.

Soft bristles

■ Remove stubborn dirt and rinse it away.

Bristles all over

■ For cleaning even in awkward places.

COMPATIBLE MACHINES

- **■** OC 3
- OC 3 Foldable