# **KÄRCHER**

# FP 303

The FP 303 floor polisher from Kärcher is lightweight, easy to transport and ideal for polishing all hard floor surfaces. Buff and polish your way to streak-free results with the FP 303.



### Order no.

### 1.056-851.0

- Perfect polishing result thanks to high pad rotation
- Ergonomic construction and optimized shape
- Accessory storage on the device

#### Technical data 4054278975948 EAN code 1000 Rotational speed rpm w 600 Rated input power Working width mm 290 Filter bag capacity I 4 V/Hz 220 - 240 / 50 - 60 Current type Weight without accessories kg 7 Weight incl. packaging kg 8.6 Dimensions (L × W × H) 385 × 339 × 1162 mm

Polishing pads	Piece(s)	3
Filter bag		Paper
Cable rewind		
Textile bag incl. accessory compartment		•

FP 303, 1.056-851.0, 2025-06-22

## KARCHER





Ergonomic handle

• For convenient and effortless cleaning.



Cord storage directly on the handle

• For easy and tidy storage of the cord on both cord hooks.



High-quality textile bag, includes separate accessory compartment


• For space-saving storage of the polishing pads provided.

## KARCHER

## **EQUIPMENT FOR FP 303** 1.056-851.0

9

8





5







		Order no.	Description	
VACUUM POLISHERS				
Polishing pads				
Polishing pads (universal)	1	2.863-193.0	3 polishing pads for FP 303 vacuum floor polisher. Ideal for polishing hard surfaces such as parquet, stone, linoleum, cork, PVC and laminate floors.	
Waxed parquet polishing pads	2	2.863-196.0	0 3 polishing pads for FP 303 vacuum floor polisher. Ideal for polishing waxed hard surfaces, e.g. waxed parquet floors.	
Sealed parquet/laminate polishing pads	3	2.863-197.0	3 polishing pads for FP 303 vacuum floor polisher. Ideal for polishing sealed hard surfaces such as sealed parquet, cork and laminate.	
Stone/Linoleum/PVC polishing pads	4	2.863-198.0	3 polishing pads for FP 303 vacuum floor polisher. Ideal for polishing matt stone, PVC or linoleum floors.	
Filter				_
Paper filter bags	5	6.904-128.0	3 replacement paper filter bags for FP 303 vacuum floor polisher.	
BASIC CLEANERS				<u> </u>
Stone, linoleum, PVC				
General purpose cleaner for stone/linoleum/PVC	6	6.295-775.0	The Kärcher general cleaning agent for stone, linoleum and PVC allows you to throughly remove old protective layers and stubborn dirt from stone, linoleum and PVC. For the best results when using this general purpose cleaner, use together with Kärcher care products. This product can also be used for normal cleaning of sealed parquet and cork, however, it is not suitable for unsealed wooden surfaces.	
FLOOR CARE				
Waxed parquet				
Floor care waxed parquet/parquet with oil-wax finish	7	6.295-778.0	The Kärcher floor care detergent for waxed parquet and parquet with an oil or wax finish is the optimal choice for the care and protection for your waxed wooden or wooden floors with an oil finish. With this floor care product, traces are removed, the protective film is renewed and the floor is left with a silky shine. Leave your treated floors to dry for 24 hours, do not apply water, move furniture or walk on the floor wearing shoes. Store your floor care detergent in a frost-free place.	0
Varnished parquet, laminate				
Floor Care for sealed parquet / laminate / cork RM 531	8	6.295-777.0	The Kärcher floor cleaner for sealed parquet, laminate and cork helos you achieve the optimum care and protection for parquet, laminate and cork floors. Traces are removed, the protective film is renewed and the floor is left with a silky shine. Leave your floors for 24 hours to harden, do not apply water, move furniture or walk over the floor in shoes. Store in a frost-free place.	s
Matte stone, linoleum, PVC				
Floor cleaner for matt stone, linoleum and PVC	9	6.295-776.0	The Kärcher floor cleaner for matt stone, linoleum and PVC creates the optimal care and protection for matt artificial and natural stone floors, linoleum and PVC. Traces are removed, the protective film is renewed and the floor is left with a silky shine. When using, leave your floors to harden for for 24 hours, do not apply water, move furniture or walk on the floor wearing shoes. Store your Kårcher floor cleaner in a frost-free place.	-
■ Included in delivery. □ Available accesso	ries.	O Detergent	· · ·	

Included in delivery. 

Available accessories. 
O Detergent.