KARCHER

VC 4 CORDLESS MYHOME

Effortless vacuuming thanks to lightweight design: The VC 4 Cordless myHome takes the effort out of vacuuming in small households.







FOCUS OPEN 2023 Special Mention







Order no.

1.198-630.0


- High-performance 21.6 V battery
- 30 mins running time in normal mode
- 0.65 I container capacity

Technical data		
EAN code		4054278975375
Battery powered device		1
Power supply	Ph / V / Hz	1 / 100 - 240 / 50 - 60
Sound power level	dB(A)	< 78
Container capacity	ml	650
Battery type		Lithium-ion battery
Voltage	V	21.6
Capacity	Ah	2.5
Run time per battery charge	min	Normal mode: approx. 30 / Boost mode: approx. 18
Battery charging time with standard charger	min	345
Power supply for battery charger	V / Hz	100 - 240 / 50 - 60
Colour		White
Weight without accessories	kg	2.4
Weight incl. packaging	kg	4.4
Dimensions (L × W × H)	mm	230 × 236 × 1115

Equipment	
Battery	21.6 V / 2.5 Ah battery (1 unit)
Bagless filter system	•
Foam filter	
Air intake filter Piece(s) 1
Power control	with 2 performance levels
Universal floor nozzle	•
Crevice nozzle	•
Upholstery nozzle and soft dusting brush (2-in-1)	
Suction tube	Plastic
Small wall bracket	
Included in the scane of supply	

■ Included in the scope of supply.

KARCHER





Fine-tuned technology

- Powerful 21.6 V battery, perfectly matched with active floor nozzle.
- Optimised running time of 30 mins in normal mode.



Two-stage power control

- Ample running time to clean small households.
- Optional boost mode.
- Up to 18 minutes running time at the highest power level.



Easy to use

- The power can be adjusted quickly and easily to suit the particular application.
- Simple 1-click filter emptying.
- Includes Power Lock for ease of operation.



ACCESSORIES FOR VC 4 CORDLESS MYHOME 1.198-630.0

















		Order no.	Description		
VACUUMS				Ė	
Filters					
Exhaust air foam filter	1	2.863-317.0	The exhaust air foam filter filters fine dirt particles from the air during vacuuming and is compatible with the VC 4 Cordless myHome and VC 4 Cordless Premium myHome devices.	•	
Air inlet filter	2	2.863-319.0	Filters finer particles from the air during vacuuming: The air inlet filter is suitable for the VC 4 Cordless myHome, VC 6 Cordless ourFamily and VC 7 Cordless yourMax devices.		
Spare batteries		'			
Replacement battery	3	2.863-362.0	More run time when cleaning: the replacement battery for all variants of the VC 4 Cordless myHome extends the operating time by 30 minutes without having to stop to recharge.		
Accessory kits					
Car accessory set	4	2.863-323.0	With the car accessories set for the VC 4 Cordless myHome, VC 6 Cordless ourFamily and VC 7 Cordless yourMax model, you clean vehicle interiors in an instant.		
Nozzles					
Mini turbo brush	5	2.863-090.0	Extra suction power for maximum cleaning performance: the mini-turbo brush delivers optimal dir pick-up and removes even pet hair effectively. Available as an accessory for cordless vacuum cleaners.	t 🗆	
Soft brush	6	2.863-320.0	Cleans sensitive surfaces gently and carefully: The soft brush is the ideal accessory for the VC 4 Cordless myHome, VC 6 Cordless ourFamily and VC 7 Cordless yourMax devices.		
Hardfloor nozzle	7	2.863-322.0	The Kärcher hard floor nozzles for the bagless battery powered vacuum cleaners VC 4 Cordless myHome, VC 6 Cordless ourFamily and VC 7 Cordless yourMax even clean sensitive hard floors gently.		
Special applications					
Filter cleaning tool	8	2.863-321.0	Thanks to the filter cleaning tool for the VC 4 Cordless myHome, VC 6 Cordless ourFamily and VC 7 Cordless yourMax devices, the air intake filter can be easily cleaned.	7 🗆	

 $[\]blacksquare$ Included in the scope of supply. \qed Available accessories. \qed Detergents.