

SC 3 DELUXE EASYFIX

Heats up in just 30 seconds: The SC 3 Deluxe EasyFix, with LED illuminated ring and perfect accessory storage, cleans without any interruptions thanks to the permanently refillable water tank.



Order no.

1.513-200.0

- Convenient accessory storage directly on the device
- LED light display on the device


Technical data		
EAN code		4054278914107
Test certificate*		Removes up to 99.999% of viruses* and 99.99% of bacteria**
Area performance per tank filling	m²	approx. 75
Heating output	W	1900
Max. steam pressure	bar	max. 3.5
Cable length	m	4
Heat-up time	min	0.5
Tank capacity	1	1
Supply voltage	Ph / V / Hz	1 / 220 - 240 / 50 - 60
Weight without accessories	kg	3.3
Weight incl. packaging	kg	5.5
Dimensions (L × W × H)	mm	361 × 251 × 282

Equipment		
Child safety lock		
Safety valve		
Steam flow control		on device (two-step)
Tank		can be refilled whenever neede
EasyFix floor cleaning cloth	piece(s)	1
Microfibre cover for hand nozzle	piece(s)	1
Descaling cartridge		
Steam hose with trigger gun	m	2
Detail nozzle		
Hand nozzle		-
Round brush, small (black)	piece(s)	1
Crevice brush		
Floor nozzle		EasyFix
Integrated on/off switch		
Extension tube (2 × 0.5 m)		
-		

Included in the scope of supply.

* Through spot cleaning using the Kärcher steam cleaner, i.e. steaming for 30 seconds on the maximum steam setting in direct contact with the surface to be cleaned, 99.999% of enveloped viruses such as influenza viruses (except the hepatitis B virus) can be eliminated on most smooth, hard surfaces in the house (test germ: modified vaccinia Ankara virus). " When cleaning at a cleaning speed of 30 cm/s using the maximum steam setting and with direct contact with the surface to be cleaned, 99.99% of all common household bacteria on common smooth, hard household surfaces are killed (test germs: Enterococcus hirae).

KARCHER





Short heat-up time

• With a heat-up time of only 30 seconds, the device is ready to use in no time.



Convenient accessory storage and parking position

• Convenient storage of accessories, extension tube, cables and steam hose.



Non-stop steam and integrated descaling cartridge

- The tank is easy to fill at any time for non-stop steam without interrupting your work.
- Thanks to the intelligent descaling cartridge, limescale is removed automatically from the water.

KARCHER

ACCESSORIES FOR SC 3 DELUXE EASYFIX 1.513-200.0



		Order no.	Description	
STEAM CLEANER / STEAM VACUUM CLEA	NER / IRONI	NG STATION		
Nozzles				
EasyFix floor nozzle set	1	2.863-267.0	With convenient hook-and-loop system and compatible microfibre floor cloth: The floor nozzle set EasyFix for steam cleaners enables the cloth to be replaced without having to come into contact with dirt.	
Hand nozzle	2	2.884-280.0	Hand tool with additional brushes for cleaning small areas such as shower cubicles, wall tiles, etc. Suitable for use with or without cover.	
EasyFix Mini floor nozzle set	3	2.863-280.0	With convenient hook-and-loop system and compatible microfibre floor cloth: The EasyFix Mini floor nozzle set for steam cleaners enables cloth replacement without having to come into contact with dirt. Especially suitable for use in small spaces and hard-to-reach areas.	
Carpet glider	4	2.863-269.0	Also ensures fresh carpet fibres: The carpet glider for easy attachment to the floor nozzle EasyFix. Ideal for steam cleaning carpets.	
Mini carpet glider	5	2.863-298.0	Freshens up even irregularly shaped and difficult-to-reach carpeted surfaces using steam: the Mini carpet glider for effortless attachment to the EasyFix Mini floor nozzle without coming into contact with any dirt at all.	
Window nozzle	6	2.863-025.0	Window nozzle for very easy and deep cleaning of glass, windows or mirrors with the steam cleaner.	
Power nozzle set	7	2.863-263.0	The power nozzle set contains a power nozzle incl. extension piece. Perfect for effortless, eco-friendly cleaning in hard-to-reach areas, e.g. corners and crevices.	
Textile care nozzle	8	2.863-233.0	Textile care nozzle for freshening up and smoothing clothes and textiles, as well as the effective elimination of odours. With integrated lint remover.	
Miscellaneous				
Descaling cartridge	9	2.863-018.0	Fast and effective descaling for Kärcher steam cleaners. All you need to do is insert the cartridge, and you're done.	
Wallpaper stripper	10	2.863-062.0	Wallpaper stripper ideal for removing wallpaper and glue residues using the power of steam.	
Sets of brushes				
Crevice brush set	11	2.863-324.0	Effortless and efficient crevice cleaning, all without chemicals: The practical crevice brush set comprises four black sets of crevice bristles and is perfect for cleaning tile joints.	
Round brush set	12	2.863-264.0	Practical round brush set with two black and two yellow brushes – perfect for use in different areas.	
Round brush kit with brass bristles	13	2.863-061.0	Round brush set with brass bristles for removing stubborn and ingrained dirt. Ideal for sensitive surfaces.	
Big round brush	14	2.863-022.0	Use the large round brush to clean large areas in less time.	

 \blacksquare Included in the scope of supply. $\hfill\square$ Available accessories. O Detergents.

KARCHER

ACCESSORIES FOR SC 3 DELUXE EASYFIX 1.513-200.0

6



22



23









		Order no.	Description					
STEAM CLEANER / STEAM VACUUM CLEANER / IRONING STATION								
Sets of brushes								
Steam turbo brush	15	2.863-159.0	No more tedious scrubbing! The steam turbo brush stands for effortless cleaning in half the time. It makes your work noticeably easier, especially when cleaning crevices, joints and corners.					
Cloth kit		•						
Abrasive cloth set abrasiv for floor nozzle EasyFix	16	2.863-309.0	The EasyFix abrasive floor cleaning cloths remove even stubborn stains from scratch-resistant stone floors. The hook-and-loop system allows easy attachment and removal without contact with dirt.					
Microfibre cloth set for bathrooms	17	2.863-266.0	The high-quality microfibre cloth set for steam cleaning in the bathroom contains two high-quality microfibre floor cloths, a microfibre abrasive cover for the hand nozzle and a microfibre polishing cloth.					
Microfibre cloth set for kitchens	18	2.863-265.0	The microfibre cloth set for steam cleaning in the kitchen contains two high-quality microfibre floor cloths, a microfibre cover for the hand nozzle and a microfibre stainless steel cloth.	r 🗆				
Microfibre cloth set for floor nozzle EasyFix	19	2.863-259.0	Cloth can be changed without having to come into contact with dirt: the high-quality Easyfix microfibre floor cloth. Thanks to the hook-and-loop system, they are easy and quick to attach to and remove from the EasyFix steam cleaner floor nozzle.					
EasyFix Mini microfibre cloth set for floor nozzle	20	2.863-296.0	Cloth can be changed without having to come into contact with dirt: The high-quality EasyFix Mini microfibre floor cloths. Thanks to the hook-and-loop system, they are easy and quick to attach to and remove from the EasyFix Mini steam cleaner floor nozzle.					
EasyFix disposable cloth set	21	2.863-299.0	Set of 15 disposable cloths for the EasyFix floor nozzle for fast and hygienic cleaning of hard surfaces. The yellow hook-and-loop strips enable the cloth to be attached easily.					
EasyFix Mini disposable cloth set	22	2.863-300.0	Set of 15 disposable cloths for the EasyFix Mini floor nozzle for fast and hygienic cleaning of hard surfaces. The yellow hook-and-loop strips enable the cloth to be attached easily.					
Microfibre cover set for the hand nozzle	23	2.863-270.0	The set with two covers for the hand nozzle. The covers are made of high-quality microfibre – for the best results when loosening and picking up dirt.					

 \blacksquare Included in the scope of supply. $\hfill\square$ Available accessories. O Detergents.