

PCL 4 PATIO CLEANER

Thanks to its rotating roller brushes and integrated water distribution, the PCL 4 patio cleaner removes dirt from wooden patios thoroughly and evenly.



Order no.

1.644-000.0

- Exchangeable roller brushes to increase cleaning versatility
- Storage rest that protects the bristles

Technical data		
EAN code		4054278505510
Max. pressure	bar	10
Pressure range		Low pressure
Water consumption at 4 bar	l/h	max. 180
Rated input power	kW	0.6
Brush rotational speed	rpm	600 - 800
Roller brush working width	mm	300
Weight without accessories	kg	5
Weight incl. packaging	kg	6.7
Dimensions (L × W × H)	mm	1281 × 307 × 350

Equipment

Edolbuleur			
Roller brushes for wooden surfaces	piece(s)	2	
Two water nozzles		•	
Valve for controlling the water volume		•	
Storage position			
Ergonomic handle and grip			
Included in the scope of supply.			

KARCHER





Two high-quality rotating roller brushes (included in the scope of supply for wooden surfaces)

• Thorough and even cleaning of wooden surfaces in outside areas with good area performance.



Two nozzles above the roller brushes

• Loosens and removes dirt in a single step. Removes stubborn dirt.




Water volume can be regulated via a valve

Water-efficient cleaning.

KARCHER

ACCESSORIES FOR PCL 4 PATIO CLEANER 1.644-000.0



		Order no.	Description	
PATIO CLEANER				
Roller brushes stone surfaces	1	2.644-121.0	The ideal addition for cleaning patios and balconies: The two-part roller set for the PCL 4 patio cleaner. Effortlessly removes organic growth and moss from smooth stone tiles in outside areas.	
Roller brushes wooden surface	2	2.644-226.0	Dirt in outside areas is removed completely and evenly with the brush heads of the two-part roller set for the PCL 4. Wooden surfaces and WPC floor coverings will look good as new again.	

■ Included in the scope of supply. □ Available accessories. ○ Detergents.