

WB 130 ROTATING WASH BRUSH


Always in motion: The rotating wash brush with interchangeable attachment cleans smooth surfaces such as paint, glass or plastic. Quick attachment changes thanks to the integrated release lever.



Order no. 2.644-286.

Technical data		
EAN code		4054278862682
Colour		black
Weight	kg	0.4
Weight incl. packaging	kg	0.5
Dimensions (L × W × H)	mm	305 x 156 x 137

KARCHER



Rotating brush head

- Gentle, soft and efficient cleaning.
- Convenient and comfortable cleaning.

Attachment change via release lever

- Quicker and easier attachment change without contact with dirt.
- Always keep your hands clean.
- Choose the right attachment for different applications.

Detergent application with the brush connected to the pressure washer

■ Better dirt loosening and efficient cleaning.



COMPATIBLE MACHINES

- K 1 Entry *MX
- K 2
- K 2 Battery
- K 2 Classic
- K 2 Classic Car
- K 2 Classic Car & Home
- K 2 Classic Home
- K 2 Horizontal
- K 2 Horizontal *MX
- K 2 OPP *GB
- K 2 Power Control
- K 2 Power Control Car
- K 2 Power Control Car & Home
- K 2 Power Control Home
- K 2 Premium
- K 2 Premium Car
- K 2 Premium Home
- K 2 Premium Horizontal
- K 2 Premium Power Control
- K 2 Premium Power Control Home
- K 2 Premium VPS
- K 2 Universal Edition
- K 2 Universal Edition Car
- K 2 Universal Edition Car *MX

- K 2 Universal Edition Home
- K 2 Universal Edition O I
- K 2 Universal Edition Promo
- K 2.105
- K 3
- K 3 *GB
- K 3 Car
- K 3 Car & Home
- K 3 Classic
- K 3 Classic Car
- K 3 Classic Car & Home
- K 3 Classic Home
- K 3 Follow Me
- K 3 Home
- K 3 Horizontal
- K 3 Horizontal Plus
- K 3 Horizontal Plus Home
- K 3 Induction
- K 3 Power Control
- K 3 Power Control Car
- K 3 Power Control Car & Home
- K 3 Power Control Deck
- K 3 Power Control Home
- K 3 Power Control Home & Pipe

- K 3 Power Control Home T 5
- K 3 Premium
- K 3 Premium Power Control
- K 3 Premium Power Control Car & Home
- K 3 Premium Power Control Home
- K 4
- K 4 Classic
- K 4 Classic Car
- K 4 Classic Home
- K 4 Power Control
- K 4 Premium
- K 4 Premium Silent Veranda 60Hz
- K 5 Classic
- K 5 Classic Home
- K 5 Modular UM
- K 5 Power Control
- K 5 Premium Power Control Home
- K 5 WCM Premium
- K 7 Premium Smart Control
- K Mini
- K Mini Plus
- K2 Follow Me Cordless
- K 5 Classic Car & Home
- K 4 Classic Car



ACCESSORIES FOR WB 130 ROTATING WASH BRUSH 2.644-286.0









		Order no.	Description		
BRUSHES					
Interchangeable attachment universal for WB 130	1	2.644-289.0	Ideal for cleaning all smooth surfaces such as paint, glass or plastic: The interchangeable Universal attachment for the WB 130 rotating wash brush.		
Interchangeable attachment car & bike for WB 130	2	2.644-290.0	Perfect cleaning of cars and motorbikes: The interchangeable Car & Bike microfibre attachment for the WB 130 rotating wash brush.		
Interchangeable attachment home & garden for WB 130	3	2.644-291.0	For thorough cleaning of resistant surfaces around the home: The interchangeable Home $\&$ Garden attachment for the WB 130 rotating wash brush.		
Garden hose adapter	4	2.640-732.0	Adapter for garden hose connection – suitable for attaching all Kärcher brushes to garden hoses with the quick-coupling system.		

 $[\]hfill \square$ Available accessories. $\hfill \bigcirc$ Detergents.