KARCHER

BP 2.000-18 BARREL

The battery barrel pump BP 2.000-18 Barrel makes it possible to use precious rain water from the barrel also in gardens without a power connection. This not only saves drinking water, but also money.









Order no.


1.645-475.0

- Flexible clamping device
- Includes prefilter
- Ideal for gardens without a power connection

Technical data		
EAN code		4054278878102
Battery platform		18 V battery platform
Max. motor rating	W	80
Max. flow rate	l/h	< 2000
Delivery head	m	max. 20
Pressure	bar	max. 2
Immersion depth	m	max. 1.8
Delivery temperature	°C	max. 35
Voltage	V	18
Run time per battery charge	min	max. 25 (2.5 Ah) / max. 50 (5.0 Ah)
Colour		Yellow
Weight without accessories	kg	1.1
Weight incl. packaging	kg	1.6
Dimensions (L × W × H)	mm	173 × 135 × 316

Equipment		
Battery holder on barrel		
Fastening possibility	•	
Hose, adjustable length		
Includes prefilter	•	
Integrated on/off switch		
Hose guide		
Overcurrent circuit breaker		
Included in the scope of supply.		

KARCHER





Variable position of the hose outlet in 3 positions

■ Perfect adjustment to every application.



18 V Kärcher Battery Power battery platform

Real Time Technology with LCD battery display:
 Remaining running time, remaining charging time and battery capacity. Long-lasting and powerful thanks to lithium-ion cells. The exchangeable battery can be used in all other 18 V Kärcher Battery Power platform devices.



Flexible clamping device

Perfect hold to any barrel thanks to very high fitting accuracy.

KARCHER

ACCESSORIES FOR BP 2.000-18 BARREL 1.645-475.0





















	r no.			Order no. Description		
			BATTERIES	ERIES		
	5-034.0	1	Battery Power 18/25	ry Power 18/25 1 2.445-034.0 18 V / 2.5 Ah Kärcher Battery Power exchangeable battery with in incl. LCD display to indicate battery level. Suitable for use in all de battery platform.		
	5-035.0	2	Battery Power 18/50	ry Power 18/50 2 2.445-035.0 18 V / 5.0 Ah Kärcher Battery Power exchangeable battery with in incl. LCD display to indicate battery level. Suitable for use in all de battery platform.		
			BATTERY CHARGERS	ERY CHARGERS		
	5-032.0	3	Fast Charger Battery Power 18 V	Charger Battery Power 18 V 3 2.445-032.0 The fast charger charges the 18 V/2.5 Ah Kärcher Battery Power of just 44 minutes and can be used for all batteries on the 18 V Kärcher Battery Power of just 44 minutes and can be used for all batteries on the 18 V Kärcher Battery Power of just 44 minutes and can be used for all batteries on the 18 V Kärcher Battery Power of just 44 minutes and can be used for all batteries on the 18 V Kärcher Battery Power of just 44 minutes and can be used for all batteries on the 18 V Kärcher Battery Power of just 44 minutes and can be used for all batteries on the 18 V Kärcher Battery Power of just 44 minutes and can be used for all batteries on the 18 V Kärcher Battery Power of just 44 minutes and can be used for all batteries on the 18 V Kärcher Battery Power of just 44 minutes and can be used for all batteries on the 18 V Kärcher Battery Power of just 44 minutes and can be used for all batteries on the 18 V Kärcher Battery Power of just 44 minutes and can be used for all batteries on the 18 V Kärcher Battery Power of just 44 minutes and can be used for all batteries on the 18 V Kärcher Battery Power of just 44 minutes and can be used for all batteries on the 18 V Kärcher Battery Power of just 44 minutes and can be used for all batteries on the 18 V Kärcher Battery Power of just 44 minutes and can be used for all batteries on the 18 V Kärcher Battery Power of just 44 minutes and can be used for all batteries on the 18 V Kärcher Battery Power of just 44 minutes and can be used for all batteries on the 18 V Kärcher Battery Power of just 44 minutes and can be used for all batteries on the 18 V Kärcher Battery Power of just 44 minutes and can be used for all batteries on the 18 V Kärcher Battery Power of just 44 minutes and can be used for all batteries on the 18 V Kärcher Battery Power of just 44 minutes and can be used for all batteries on the 18 V Kärcher Batteries	-	
		RS	STARTERKIT BATTERIES AND BATTERY CHARGE	FERKIT BATTERIES AND BATTERY CHARGERS		
	5-062.0	4	Starter kit Battery Power 18/25	er kit Battery Power 18/25 4 2.445-062.0 Battery Power 18/25 Starter Kit incl. 18 V/2.5 Ah Battery Power 6 innovative Real Time Technology and 18 V fast charger. For all de platform.		.у
	5-063.0	5	Starter kit Battery Power 18/50	er kit Battery Power 18/50 5 2.445-063.0 Incl. 18 V / 5.0 Ah Kärcher Battery Power exchangeable battery an Power 18/50 Starter Kit for use in all devices on the Kärcher 18 V		/ 🗆
			HOSES	S		
	5-115.0	6	Hose set, 20 m	set, 20 m 6 2.645-115.0 Hose set with 20 m standard hose (1/2"), spray gun, G3/4 brass ta universal hose connector and universal connector with Aqua Stop.		
	5-114.0	7	Hose set with hose hanger, 15 m	set with hose hanger, 15 m 7 2.645-114.0 Hose set with hose hanger, 15 m PrimoFlex* hose (1/2"), nozzle, C universal hose connector and universal hose connector with Aqua		·, 🗆
			NOZZLES AND SPRAY LANCES	LES AND SPRAY LANCES		
	5-288.0	8	Nozzle set	e set 8 2.645-288.0 The optimal entry-level set with nozzle, tap connector and 2 conn Immediately ready for easy watering of the garden.	nectors (one includes Aqua Stop).	
	5-289.0	9	Spray gun set	gun set 9 2.645-289.0 All set to water the garden in an instant: In addition to the spray gincludes a tap adapter as well as 2 hose connectors - one of which		
	5-290.0	10	Multifunctional spray gun set Plus	functional spray gun set Plus 10 2.645-290.0 Made for a variety of garden watering applications: the multifunct adaptor and 2 connectors with grip (one with Aqua Stop).	tional spray gun includes tap	
Power exchangeable battery and 18 V fast charger: The Ball devices on the Kärcher 18 V battery platform. (1/2"), spray gun, G3/4 brass tap adaptor with G1/2 reduced ersal connector with Aqua Stop. rimoFlex* hose (1/2"), nozzle, G1 tap adaptor with G3/4 redersal hose connector with Aqua Stop. ozzle, tap connector and 2 connectors (one includes Aqua Stop of the garden. stant: In addition to the spray gun, the spray gun set also hose connectors – one of which has Aqua Stop.	5-115.0 5-114.0 5-288.0 5-289.0	6 7 8 8 9	HOSES Hose set, 20 m Hose set with hose hanger, 15 m NOZZLES AND SPRAY LANCES Nozzle set Spray gun set	platform. 2.445-063.0 Incl. 18 V / 5.0 Ah Kärcher Battery Power exchangeable battery and Power 18/50 Starter Kit for use in all devices on the Kärcher 18 V set, 20 m 6 2.645-115.0 Hose set with 20 m standard hose (1/2"), spray gun, G3/4 brass ta universal hose connector and universal connector with Aqua Stop. set with hose hanger, 15 m 7 2.645-114.0 Hose set with hose hanger, 15 m PrimoFlex* hose (1/2"), nozzle, Guniversal hose connector and universal hose connector with Aqua Stop. Universal hose connector and universal hose connector with Aqua Stop. The optimal entry-level set with nozzle, tap connector and 2 connumediately ready for easy watering of the garden. 9 2.645-289.0 All set to water the garden in an instant: In addition to the spray gincludes a tap adapter as well as 2 hose connectors - one of which functional spray gun set Plus 10 2.645-290.0 Made for a variety of garden watering applications: the multifunctional	and 18 V fast charger: The Bay battery platform. ap adaptor with G1/2 reduced. G1 tap adaptor with G3/4 real stop. according to the stop of the stop of the stop. gun, the spray gun set also has Aqua Stop.	er, ducer

 $[\]blacksquare$ Included in the scope of supply. \qed Available accessories.