

SHOE!CLEANER SE 3 COMPACT, SE 4, 5 AND 6

Fast and drip-free shoe cleaning: the Shoe!Cleaner is the perfect accessory for thorough cleaning of sports footwear and casual shoes. For the SE 3 Compact, 4, 5 and 6 spray extraction cleaners.



Order no. **2.863-370.0**

Technical data

EAN code		4066529107039
Colour		black
Weight	kg	0.1
Weight incl. packaging	kg	0.1
Dimensions (L x W x H)	mm	124 x 65 x 44



Innovative Kärcher technology for optimum cleaning results

- Replaceable brush crown for thorough cleaning of soles and shoe uppers.
- Drip-free application because water is automatically vacuumed during the cleaning process.
- Low residual moisture for quick drying of textile surfaces.



Simple and convenient handling

- The system cleaning function prevents accessories from becoming dirty during cleaning applications. Hands stay clean and accessories can be stowed away immediately after use.
- Intuitive operation.



Soft bristles

- Dirt is removed from shoes thoroughly yet gently.
- Leaves no traces behind when cleaning sensitive surfaces.

COMPATIBLE MACHINES

- SE 3 Compact
- SE 3 Compact Home
- SE 3 Compact Home Floor
- SE 3 Compact Home N1
- SE 4
- SE 4 Plus
- SE 4 Plus Special
- SE 4 Select
- SE 5
- SE 5 Car
- SE 5 Upholstery
- SE 6 Signature Line
- SE 6 Ultra Clean Spray Extraction Cleaner
Signature Line