## **KARCHER**

makes a difference

## BATTERY HOISTING QUICK START BD 90/160 R Classic Bp

Remove the two screws on the plastic part in front of the seat 拧开座椅前塑料件上的两颗螺钉



Take out the two screws from the side plastic 拧开侧边塑料件上的两颗螺钉



please be sure to read carefully to avoid damage to the equipment before use machine 使用机器前,请确保仔细阅读该指南,避免损伤机器





makes a difference

## **BATTERY HOISTING QUICK START**

BD 90/160 R Classic Bp

