

A close-up photograph of a person wearing white protective pants and white safety shoes with orange accents, operating a grey Kärcher floor scrubber machine. The person's right foot is on a pedal of the machine. The machine has a large black wheel and a red brush roll. The Kärcher logo is visible in the top center of the image.

KÄRCHER

REINIGUNG VON SCHEUERSAUG- MASCHINEN.

Adäquate Schutzmaßnahmen können die
Ausbreitung von COVID-19 eindämmen.

kaercher.com


01

Desinfektion vor Gebrauch

Lenkrad oder Bedienpanel desinfizieren

Schalter, Knöpfe, Ablage desinfizieren

Frischwassereinfüllöffnung und Tankdeckel desinfizieren



Bei Aufsitzmaschinen Sitz desinfizieren



Wichtig

In jedem Schritt der Desinfektion und Reinigung:

Immer Einweghandschuhe tragen.

Gebrauchte Wischtücher und Handschuhe entsorgen.





02

Reinigung und Desinfektion nach Gebrauch

Frisch- und Schmutzwasser ablassen, anschließend Tanks mit klarem Wasser ausspülen

Grobschmutzkorb ausspülen und desinfizieren

Alle Oberflächen außen und erreichbare Flächen im Inneren (Schmutzwassertank, Ablagefächer usw.) desinfizieren



Scheiben-, Walzenbürsten oder Padtreibteller mit Pad reinigen und desinfizieren

Saugbalken und -lippen reinigen und desinfizieren