

76 Scrub the floor B110



Make sure you have read, understood and signed off these Safe Work Practices

SWP 003
Housekeeping

SWP 006
Manual handling

SWP 018
Electrical equipment

SWP 142
Chemicals

SWP 400 Buffer and Scrubber machine

Equipment

- ✓ Safety sign
- ✓ Disposable gloves
- ✓ Goggles (When dispensing chemicals)
- ✓ Clean water
- ✓ Scraper
- ✓ Clean cloths
- ✓ Scourer/Magic Sponge
- ✓ Auto scrubber machine B110 Ride On
- ✓ Pioneer Eclipse Rebound (refer to floor schedule)
- ✓ Pioneer Eclipse Neutral Cleaner (refer to floor schedule)



WARNING! – DO NOT use the machine if it is not operating correctly or damaged. Report it immediately to your Manager on duty, then let your Line Manager know.



Step 1
Put on disposable gloves and erect safety sign in place




Step 2
Turn off the power, unplug the charger from the mains by firmly holding the plug. Wind the mains cable and secure neatly under the seat



Step 3 (Auto fill connection)
Open the auto fill tank lid, connect the hose to fill with clean cold water



Step 3 (No auto fill connection)
Open front fill point and use hose to fill with clean cold water



Step 4 (without auto dose)
Wearing safety goggles and gloves, measure the correct chemical amount, pour into the fresh water tank. Refer to Daily Floor Care chart for correct chemical dosage



Step 4 (with auto dose)
Check the correct chemical is in the machine, and there is enough chemical to complete the task. Refer to Daily Floor Care chart for correct chemical dosage



Step 5
Attach pad to the pad driver by inserting pad under the central hub



Step 6
Attach pad driver to scrubber machine by locating the hub and using 2 hands to push up into place until it clicks. Repeat on other side

Continued over the page. ➔

76 Scrub the floor B110 continued



Step 7
Insert the yellow operator KIK key



Step 8
Turn the program selector switch to position 1 "Transport mode"



Step 9
Set the drive direction with the drive direction button
➔ Forward
➔ Reverse



Step 10
Determine the driving speed by pressing the pedal



Step 11
To stop, release the drive pedal



Step 12
Drive the machine to the start of the cleaning area



Step 13
Select the relevant cleaning mode. The brush/pad head and squeegee will lower automatically when the drive pedal is pressed



Step 14
When floor scrubbing is finished, set the program selection switch to suction/vacuum




Step 15
Briefly drive forward for approx. 10 metres to suck up the remaining water



Step 16
Turn the program selector to transport mode




Step 17
Drive to cleaning area



Step 18
Turn machine to off position



Step 19
Take the water discharge hose from the support and lower above a suitable drain. Twist slowly to open



Step 20
Lift the waste water tank lid. Remove the debris basket, empty it into a bin

Continued
over the
page. ➔

76 Scrub the floor B110 continued



Step 21
Rinse the waste water tank and debris basket



Step 22
Place basket back into the waste water tank



Step 23
Check lint filter, wipe clean if required. **Be careful to keep water away from this area**




Step 24
Leave the cover open to allow it to dry



Step 25
Slowly unscrew the filter cap of the fresh water filter and let the fresh water tank drain completely. Replace the filter cap and ensure no water leaks



Step 26
Kneel with kneeling pad, lift the yellow handles to release squeegee. Use 2 hands and keep your back straight to lower to the ground, before using SMART moves to lift and move over the drain area



Step 27
Clean squeegee by rinsing with clean water and then wiping the blade. Check the condition of the blade before returning it to the machine



Step 28
Return squeegee to the machine. Use SMART moves to lower it to the ground, kneel with a kneeling pad, use 2 hands, keep your back straight lift it into place



Step 29
Wipe skirt clean with a damp cloth



Step 30
Remove pads by pushing the pedal




Step 31
Wash pads and hang to dry in the Coles Services Department



Step 32
Move machine to the correct storage area, remove the KIK key



Step 33
Insert the plug of the connecting cable into the socket and turn power on to charge




Step 34
Return safety sign to the correct position in the Coles Services Department

Continued
over the
page. →

76 Scrub the floor B110 continued



- **REMEMBER** Always drive the machine at a safe working speed. Release the driving pedal to stop the machine
- Never move or operate the machine without the pad or brush, to prevent the hub hitting the floor and damaging the machine
- If the fresh water tank drains before you have finished scrubbing. Refill it completely to ensure the correct amount of chemical is added
- Use your scourer and scraper to remove difficult marks and stickers
- When scrubbing, always start on either the right or left hand side of an aisle, never the middle
- When removing/replacing the squeegee, always kneel with a kneeling pad. Do not lift while you are bending over or squatting and balancing on your feet as the weight may pull you forward and off balance



- a) **Eco mode**
Wet clean the floor and vacuum up dirty water
Recommended water setting 20% - 30%
- b) **Normal mode**
Wet clean the floor and vacuum up dirty water
Recommended water setting 50% - 60%
- c) **Heavy mode (Increased brush contact pressure)**
Wet clean the floor (with increased brush contact pressure) and vacuum up dirty water
Recommended water setting 70% - 80%
- d) **Scrub mode (no suction)**
Wet clean the floor and allow the detergent to react
- e) **Vacuum mode (no scrubbing)**
Vacuum the wastewater
- f) **Polishing mode**
Polish the floor without the application of liquid