

KÄRCHER

QUICK START GUIDE - HV 1/1 Bp

HANDHELD BATTERY-POWERED VACUUM CLEANER



KÄRCHER

THE MACHINE



Machine components

- Hand vac unit
- Filter
- Battery & charger



Facility accessories

- Crevice nozzle
- Floor tool
- Upholstery nozzle
- Suction brush
- 2 x suction tubes



Construction accessories

- Flexible suction hose
- Carrying strap
- Crevice nozzle
- Suction brush

Automotive accessories

- Car nozzle
- Crevice nozzle
- Flexible suction hose

HOW TO SET-UP



Insert filter into the head of the machine.



Simply clip the waste container and base of the machine into place.



Slide the battery into place at the base of the machine.

MACHINE OPERATION



Press the trigger once to start cleaning straight away.



To activate eco!efficiency mode, press the blue button on the back of the machine.

Note: Eco mode increases run time from 21 minutes to a max of 35 minutes and decreases operating volume making it perfect for use in noise sensitive areas.



To clean difficult to reach areas you can easily rotate the nozzle. To do this, press the yellow button on the front of machine.



For different cleaning applications, apply the relevant accessory by attaching the nozzle of the machine.

KÄRCHER

BATTERY CHARGING



The battery charge status is displayed via the power button on the front on the device.



To remove the battery simply hold and pull the yellow release mechanism.



Plug in quick charger.



Place the lithium-ion battery into the quick charger. A full charge takes only 50 minutes with progress shown via the charger light indicators.

CORRECTLY MAINTAINING YOUR MACHINE



To remove and clean the filter, press both yellow buttons either side of the machine to remove head and give access to the filter.



Simply remove the filter to dispose of the waste in the container.



To clean the filter, remove prefilter cover and tap it lightly to remove debris.

AVAILABLE ACCESSORIES



Flexible suction hose



Plastic suction tube set



Car nozzle



Crevice nozzle



Floor tool



Suction brush



Additional battery charger and battery pack



Carrying strap



Upholstery nozzle