

CarpetPro Cleaner iCapsol RM 768

CarpetPro Cleaner iCapsol RM 768 for intermediate cleaning. Dry foam with encapsulation technology: Dirt is encapsulated and suctioned during the next maintenance cleaning.

pH 6.1 in concentrate



Retail











Properties

- Very short drying time (just 20-120 minutes).
- iCapsol technology: no rinsing required, so surfaces are soon dry again
- Dissolves oil, grease and mineral stains
- Particularly suitable for carpet cleaners with a brush or pad system
- Gentle cleaning action
- Free from bleaching agents
- Pleasant, fresh fragrance

Application

- Carpet cleaners
- Single-disc machines

Areas	
Contract cleaning	Textile surfaces
Retirement homes, doctor's surgery	Textile surfaces
Hotels, gastronomy, catering	Textile surfaces
Municipal	Textile surfaces

Textile surfaces

recnnical data					
Container sizes	Packaging unit	Part number			
10 Litro	1 Unit	6 295-562 0			



Application

Carpet cleaner

- Vacuum textile surfaces.
- Combine the product with the appropriate dosage and fresh water.
- Pour in the product undiluted for devices with integrated cleaning agent tank.
- Spray textile surfaces evenly with cleaning solution.
- Work in with brush or pad system, either simultaneously or subsequently.
- Leave the object to fully dry.
- Vacuum the encapsulated dirt with a Kärcher brush vacuum cleaner for carpets.

Single-disc machine

- Vacuum textile surfaces.
- Combine the product with the appropriate dosage and fresh water.
- Spray textile surfaces evenly with cleaning solution.
- Vacuum the foam.
- Then work in with brush or pad system.
- Leave the object to fully dry.
- Vacuum the encapsulated dirt with a Kärcher brush vacuum cleaner for carpets.

Directions for use

- Test on an inconspicuous part for material compatibility.
- Do not soak materials.
- Leave the floor to fully dry before vacuuming.
- WoolSafe certified for the application concentration

Warnings and safety recommendations according to EC Directives

- Warning
- H315 Causes skin irritation
- H319 Causes serious eye irritation
- P280 Wear protective gloves/protective clothing/eye protection/face protection.
- P264 Wash thoroughly after handling.
- P305 + P351 + P338 IF IN EYES: Rinse cautiously with water for several minutes. Remove contact lenses, if present and easy to do. Continue rinsing.
- P332 + P313 If skin irritation occurs: Get medical advice/attention.
- P337 + P313 If eye irritation persists: Get medical advice/attention.
- P302 + P352b IF ON SKIN: Wash with plenty of soap and water.

Further information

■ Material Safety Data Sheet (MSDS)

Dosage and yield					
Contents	Cleaning method	Dosage	Type of dirt	Yield	
1000 Millilitre	Interim cleaning	6 Percent	light	330 Square metre	