

CarpetPro Cleaner iCapsol RM 768 OA

Powerful dry foam CarpetPro Cleaner iCapsol RM 768 OA with odour eliminator. With encapsulation technology: Dirt is encapsulated and is vacuumed off when you next clean.

pH 8.5
in concentrate



Properties

- With integrated odour eliminator. Effectively eliminates unpleasant odours such as sweat, urine, nicotine, etc.
- Very short drying time (just 20-120 minutes).
- iCapsol technology: no rinsing required, so surfaces are soon dry again
- Removes oil, grease and mineral contamination
- Ideal for carpet cleaners with brush or pad system
- Gentle on materials
- Free from bleaching agents
- Improves hygiene of floor
- Pleasant, fresh scent

Usage options

- Carpet cleaners
- Single disc machines

Application areas

Building cleaning	Textile surfaces
Nursing and retirement homes, doctor's surgeries	Textile surfaces
Hotels, gastronomy, catering	Textile surfaces
Municipal	Textile surfaces
Retail	Textile surfaces

Technical data

Container sizes	Packaging unit	Part number
10 l	1 Piece(s)	6.295-634.0

Application

Carpet cleaner

- Vacuum textile surfaces.
- Combine the product with the appropriate dosage and fresh water.
- Pour in the product undiluted for devices with integrated detergent tank.
- Spray textile surfaces evenly with cleaning solution.
- Work in with brush or pad system, either simultaneously or subsequently.
- Leave the object to fully dry.
- Vacuum the encapsulated dirt with a Kärcher upright brush-type vacuum cleaner.

Single-disc machine

- Vacuum textile surfaces.
- Combine the product with the appropriate dosage and fresh water.
- Spray textile surfaces evenly with cleaning solution.
- Vacuum the foam.
- Then work in with the brush or pad system.
- Leave the object to fully dry.
- Vacuum the encapsulated dirt with a Kärcher upright brush-type vacuum cleaner.

Instructions for use

- Test on an inconspicuous part for material compatibility.
- Do not soak materials.
- Leave the floor to fully dry before vacuuming.

Warnings and safety recommendations according to EC Directives

- Warning
- H315 Causes skin irritation
- H319 Causes serious eye irritation
- P280 Wear protective gloves/protective clothing/eye protection/face protection.
- P264 Wash thoroughly after handling.
- P305 + P351 + P338 IF IN EYES: Rinse cautiously with water for several minutes. Remove contact lenses, if present and easy to do. Continue rinsing.
- P332 + P313 If skin irritation occurs: Get medical advice/attention.
- P337 + P313 If eye irritation persists: Get medical advice/attention.
- P302 + P352b IF ON SKIN: Wash with plenty of soap and water.

Further information

- Material Safety Data Sheet (MSDS)

Dosage and yield

Contents	Cleaning method	Dosage	Soiling	Yield
1000 ml	Intermediate cleaning	6 %	light	330 m ²