



## FloorPro High Gloss Crystallising Agent, powder RM 775

Crystallising agent for treating and hardening marble and terrazzo floors. After crystallisation the floor has an attractive high gloss and is harder and more resistant to wear. NTA free.



### Properties

- Effective high-gloss crystallising agent for all calcareous stone floors, such as marble, terrazzo, cast stone
- Powder-form
- Produces a resistant surface by compressing the stone
- Produces a high-gloss mirror finish
- The character of the stone is maintained
- Makes future cleaning of the surfaces easier (less subsequent soiling)
- Especially productive
- Immediately accessible again after application
- NTA free

### Areas:

<b>Car dealership and garage:</b>	Calcic stone floors
<b>Contract cleaning:</b>	Calcic stone floors
<b>Hotels, gastronomy, catering:</b>	Calcic stone floors
<b>Municipal:</b>	Calcic stone floors
<b>Retail:</b>	Calcic stone floors

### Application

- Single-disc machines

pH

**1.4**  
in concentrate



5 kg

Part number

6.295-117.0

**Application:****Single-disc machines - crystallising**

- Clean surface thoroughly.
- Rinse with plenty of clear water and soak in water until all dirt and cleaning agent residues have been removed.
- Leave to dry.
- Set up the device with the appropriate pad.
- 
- Per m<sup>2</sup>, distribute paste evenly over the surface with a pad.
- Polish surface immediately with device until a high-gloss is achieved.
- Brush off the crystallising agent from the surface with plenty of water and standard brushes.
- Vacuum surface with wet and dry vacuum cleaner.

**Directions for use:**

- Test on an inconspicuous part for material compatibility.
- Fine grind any heavy wear and scratches on the floor before treatment.
- Store in a dry place.

**Warnings and safety recommendations according to EC Directives:**

- Danger
- H302 + H312 Harmful if swallowed or in contact with skin
- H318 Causes serious eye damage
- P280a Wear protective gloves / eye protection / face protection.
- P301+P312a IF SWALLOWED: Call a POISON CENTER/doctor if you feel unwell.
- P330 Rinse mouth.
- P302 + P352a IF ON SKIN: Wash with plenty of water.
- P305 + P351 + P338 IF IN EYES: Rinse cautiously with water for several minutes. Remove contact lenses, if present and easy to do. Continue rinsing.
- P310 Immediately call a POISON CENTER/doctor.

**Further information:**

- Material Safety Data Sheet (MSDS)

**Dosage and yield:**

Content:	Cleaning method:	Primary mixture:	Dosage:	Contamination:	Productivity:
1 kg	Crystallising		30 g/m <sup>2</sup> undiluted		30 m <sup>2</sup>

Please contact us for more information:

**Kärcher UK Ltd**

Kärcher House  
Brookhill Way  
Banbury  
Oxon OX16 3ED